

APV PRO series

Vector type frequency converter instruction manual



V202.xx

APV Pro Series Frequency Inverter Instruction Manual

The illustrations in this instruction manual are for illustrative purposes only and may differ slightly from the actual product. Due to product upgrades, there may also be slight differences. Please refer to the actual product for accuracy.

Please ensure that this instruction manual is delivered to the end user and kept safe for future inspection and maintenance.

If you have any questions, please contact our company or our agents promptly. We are happy to assist you.

1. Safety Precautions

Read this instruction manual carefully before installing, operating, maintaining, or inspecting.

The safety precautions in the instruction manual are categorized as "Warnings" or "Caution".



It points out potential dangers that, if not avoided, could lead to personal injury or death.

This avoided, could and equipment against unsafe



indicates potential hazards that, if not result in minor to moderate personal injury damage. It can also be used to warn practices.

In some cases, even the precautions mentioned **above can lead to serious accidents. Therefore, it is essential to follow these important precautions in all circumstances.**

★ **Note** the steps taken to ensure correct operation.
Warning labels are displayed on the front cover of the drive unit.
Follow these guidelines when using the driver.

Warning mark

DANGER

- Risk of injury and electric shock.
- Read the manual and follow the safety instructions before use.
- solate from supply and wait 10minutes before removing his cover.
- Ensure proper earth connection.
- Mount the inverter on a non-combustible surface.

2. Unpacking and inspection



- Do not install or run any drives that are damaged or have faulty parts, as this could result in injury.

After unpacking and removing the drive, please check the following items.

① Confirm that the drive was not damaged during transportation (damage or nicks on the body).

② Confirm that the package contains an instruction manual and warranty card.

③ Check the driver nameplate and confirm that it is the product you ordered.

④ If you ordered optional accessories for the drive, please confirm that the received accessories are what you need.

If you find any damage to the drive or accessories, please call your local dealer immediately.

3. Disassembly and installation precautions



• The design, installation, commissioning, and operation of the equipment must be carried out by trained and qualified professionals; all provisions in the "Warnings" must be followed during the work process, otherwise serious personal injury or major property damage may occur.

• Input power cords are only allowed to be permanently and securely connected, and the equipment must be reliably grounded.

Even when the driver is not in operation, the following terminals may still carry dangerous voltages:

-Power terminals R, S, T

-Connecting the motor terminals U, V, W

• After the power switch is turned off, you must wait at least 10 minutes and allow the driver to discharge completely before you can begin the installation process.

• The minimum cross-sectional area of the grounding conductor must be at least 10 mm², or the maximum value among the two values listed in the table below must be selected as the grounding conductor area:

The cross-sectional area of the power line conductor is S mm² , and the cross-sectional area of the grounding conductor is...

	S ≤ 6	S
	16 < S ≤ 35	16
	35 < S	S/2



• When lifting the cabinet using the support base, do not grab the panel to lift it while moving the drive unit, otherwise the main unit may fall and cause personal injury.

• The drive unit should be installed on a flame-retardant material such as

APV Pro Series Frequency Inverter Instruction Manual

metal, away from heat sources and flammable objects to prevent fire.

- When installing two or more drives in a cabinet, a cooling fan must be installed and the air temperature must be controlled below 40°C, otherwise overheating may cause a fire or damage to the equipment.

Table of contents

Chapter 1 Overview 1

1-1 Comprehensive Technical Characteristics of Frequency Converters

1

Chapter One Overview

1-1 Comprehensive Technical Characteristics of Frequency

Converters

project		Specification
Basic	highest frequency	0 ~ 60 0Hz
	carrier frequency	0.5kHz ~ 16kHz It can automatically adjust the carrier frequency according to the load characteristics.
	Input frequency resolution	Digital setting: 0.01Hz Simulation settings: Maximum frequency × 0.025%
	Control method	Open-loop vector control (without PG) V/F control
	Starting torque	Model G : 0.5Hz/150% (without PG);
	Speed range	1 : 100 (No PG)
	Speed stability	±0.5% (without PG)
	Torque control accuracy	±5% (FVC)
	Overload capacity	Type G : 150% rated current for 60 seconds ; 180% rated current for 3 seconds .
	Torque boost	Automatic torque boost; manual torque boost of 0.1%~30.0%.
	V/F curve	Three types: linear; multi-point; Nth power V/F curve (1.2 , 1.4 , 1.6 , 1.8 , 2)
	V/F separation	Two methods: full separation and partial separation
	Acceleration/deceleration curves	linear or S- curve acceleration/deceleration methods. Four acceleration/deceleration times, ranging from 0.0 to 6500.0 seconds.
Function	DC braking	DC braking frequency: 0.00Hz ~ maximum frequency; Braking time: 0.0s ~ 100.0s ; Braking operating current value: 0.0%~100.0%
	Jog control	Jogging frequency range: 0.00Hz~50.00Hz . The inching acceleration and deceleration time is 0.0s to 6500.0s .
	Simple PLC , multi-speed operation	16 speed settings can be achieved via built-in PLC or control terminals.

	Built-in PID	It can easily realize a closed-loop control system for process control.
	Automatic Voltage Regulator (AVR)	It can automatically maintain a constant output voltage when the mains voltage changes.
	Overvoltage and overcurrent speed control	Automatic current and voltage limiting during operation to prevent frequent overcurrent and overvoltage tripping.
	Fast rate limiting function	Minimize overcurrent faults and protect the inverter for normal operation.
	Torque Limiting and Control	" excavator " feature automatically limits torque during operation. Preventing frequent overcurrent tripping
	Protection function	Features include: motor short circuit detection, input/output phase loss protection, overcurrent protection, overvoltage protection, undervoltage protection, overheat protection, and overload protection.
Personalization features	Excellent performance	Realizing asynchronous motors using high-performance current vector control technology
	Fast rate limiting	To avoid frequent overcurrent faults in the frequency converter
	Timed control	Timer control function: Set time range 0.0 Min ~ 6500.0 Min
	Communication methods supported	RS-485 , CANopen communication, Profinet communication EtherCAT, Profibus-DP, ModbusTCP
run	command source	Operation panel settings, control terminal settings, serial communication port settings. It can be switched in multiple ways
	frequency source	Ten frequency sources: digital input, analog voltage input, analog current input, and serial port input. Switching between these sources is possible in multiple ways.
	Auxiliary frequency source	Ten auxiliary frequency sources. Allows for flexible auxiliary frequency fine-tuning and frequency synthesis.
	Input terminals	6 digital input terminals, Two analog input terminals support 0-10V voltage input or 4-20mA current input .
	Output terminals	2 relay output terminals Two analog output terminals support 0~20mA current output or 0~10V voltage output.

ring territory	Altitude	Below 1000m (above 1000m, downshifting is required)
	Ambient temperature	a lower setting if the ambient temperature is between 40°C and 50°C)
	humidity	Less than 95% RH, no water droplets condense.
	vibration	Less than 5.9 m/ s ² (0.6 g)
	Storage temperature	-20°C to +60°C
	Protection level	IP66

1-2 Process Description

Function	describe	Show code
Pump	PA03=0, positive effect: the operating frequency is greater than or equal to the pumping frequency PA.51, and the feedback value is less than the set value and the duration is greater than the pumping time PA.52, then the current pump switches to mains frequency operation and the next variable frequency pump is started . PA03=1, reaction: If the operating frequency is greater than or equal to the pumping frequency PA.51 and the duration is greater than the pumping time PA.52 , then the current pump will switch to mains frequency operation and the next pump will start operating at variable frequency .	
Pump reduction	PA03=0, positive effect: If the operating frequency is less than or equal to the pump reduction frequency PA.53, and the feedback is greater than 95% of the set value, and the duration is greater than the pump reduction time PA.54 , then the first pump put into operation should be stopped according to the principle of first-in, first-out. PA03=1, reaction: If the operating frequency is less than or equal to the pump reduction frequency PA.53, and the feedback value is less than 110% of the set value , and the duration is greater than the pump reduction time PA.54 , the first pump put into operation will be stopped according to the principle of first-in, first-out.	
Replace pump	If a variable frequency pump is running for a duration that reaches the pump replacement time FA . 55 and	

	there is an idle variable frequency pump , it will be replaced with the next variable frequency pump in operation.	
Automatic start upon power-on	Automatic startup of PA.38 upon power-on is invalid if PA.38=0; PA.38's factory default value is 0.	
Pressure setting and display	FA.02 Target value setting: 0 : PA.04 Set the target pressure; UP and DOWN can be modified .	
Terminal to shut off water pump function	Multi-function terminal for shutting off water pump: 5.1 : Pump 1 is ineffective . 5 2 : Pump 2 is not working. 53 : Pump 3 is ineffective. 54 : Pump 4 is not working. When the corresponding input terminal is closed 1) If the water pump is running at mains frequency, immediately disconnect the motor. 2) If the water pump is operating at a variable frequency and there is an idle pump, then immediately proceed with the pump replacement process. 3) If the water pump is operating at variable frequency and there is no idle pump, the pump operating at industrial frequency will stop, and after a delay, it will switch to variable frequency operation.	
PID sleep function	1) When pressure is reached, the operating frequency is less than the sleep frequency PA.29, and the duration is greater than the sleep time PA.30. The frequency drops to 0, and the system enters sleep mode, displaying "SLP". 2) When the operating frequency is higher than the sleep frequency PA.29, and the frequency is stable, the inverter can intelligently identify this and will enter sleep mode. The relevant parameters are PA.45~PA.48. 3) If the frequency is greater than PA.49, do not determine if it is in sleep mode. 4) The system will only enter sleep mode when only one variable frequency pump is running.	SLP
PID wake-up function	PA03=0, positive effect: When the pressure drops below the set pressure of - PA.31 during sleep mode, the inverter wakes up and the PID controller starts working. PA03=1, reaction: When the feedback value increases during sleep mode and exceeds the set pressure + PA.31, the inverter	

APV Pro Series Frequency Inverter Instruction Manual

	wakes up and the PID controller starts working.	
Antifreeze function	When PA. 41 = 1, during sleep, the duration is greater than PA. 42, and the duration of PA. 43 is at the frequency of PA. 44.	
Pressure sensor disconnection detection	If the pressure sensor disconnects, the frequency converter will report a fault and display "PIDE". Refer to parameters PA26 and PA27.	20
High water pressure alarm	If the pressure exceeds PA.32 during shutdown or operation and the duration exceeds 0.1 seconds, a high pressure fault will be reported and the machine will shut down, with fault code "HP". (After the pressure returns to normal or the set pressure is less than or equal to the set pressure , PA.35 automatically resets the fault after a delay.)	HP
Low water pressure alarm	during operation and persists for a period greater than PA.36, a low pressure fault will be reported and the machine will shut down, with fault code "LP". (After pressure > PA.33 *1.1 , PA.35 automatically resets after a delay)	LP
Replace the pump if it fails	Connect the pressure sensor to the standby main pump in advance and set PA.58 . Enable FA.65 to replace the main pump and set FA.66 to become the operating source after replacing the main pump. When the main pump fails, it will switch to the standby main pump .	
Water shortage alarm	PA03=0, positive effect: "Detection frequency A" = 2Hz lower than the maximum frequency = P0.12 - 2Hz If the inverter's operating frequency is greater than "detection frequency A" and the duration is greater than PA.37, while the pressure is less than PA.34, a water shortage fault will be reported and the unit will shut down, with fault code "LL". PA03=1, reaction The water shortage alarm is no longer being interpreted.	LL
Automatic reset function for water shortage fault	In the event of a water shortage fault, the frequency converter will automatically reset the fault and resume operation. The automatic reset interval is PA.39 , and the number of water shortage self-resets is PA.40. This ensures that the unit stops operating when the tap water supply is interrupted and automatically resumes normal water supply once the tap water supply is restored.	

APV Pro Series Frequency Inverter Instruction Manual

	(In keyboard operation mode, the automatic power-on and automatic operation function needs to be enabled.)	
Variable frequency pump tripping fault	Multi-pump communication: Terminal shutdown of frequency converter pump or frequency converter pump failure. If an idle pump is available, switch to idle pump frequency conversion regulation ; if no idle pump is available, check if a mains frequency pump is available. If so, set it as a frequency conversion pump and regulate it with the mains frequency using PID control ; if no mains frequency pump is available, wait for an idle pump to become available before starting operation.	
B1~ B4	Water pump 1~ 4 shut-off function prompt	
CO1~ CO4	Communication disconnection message between the main unit and the slave pumps (pumps 1-4)	

1-3 Inverter Nameplate Description


MODEL: APV Pro-2R2G4-PN

INPUT: 3PH 380V 50Hz/60Hz
OUTPUT: 3PH 380V 5.1A
FREQ RANGE: 0.1-599Hz 2.2KW



2212311825






1-4 series frequency converters



Inverter Model	Input voltage	Rated output power (KW)	Rated input current (A)	Rated output current (A)	Applicable motor (KW)
APV PRO-0R75G-4	3PH AC 380V ±15%	0.75	3.8	2.1	0.75
APV PRO-1R5G-4		1.5	5.0	3.8	1.5
APV PRO-2R2G-4		2.2	5.8	5.1	2.2
APV PRO-3R7G-4		3.7	10.0	9.0	3.7
APV PRO-5R5G-4		5.5	15.0	13.0	5.5
APV PRO-7R5G-4		7.5	20.0	17.0	7.5
APV PRO-11G-4		11	26.0	25.0	11

1-5 Inverter Appearance and Installation Dimensions

(1) 0.75KW~3.7KW




(2) 5.5KW~11KW



Chapter Two: Inverter Wiring

The wiring of a frequency converter is divided into the main circuit section and the control section.

2-1 Main circuit wiring



2-1-1 Peripheral Component Description

(1) AC power supply

Please use the power supply specified in the instruction manual.

(2) Fuseless Circuit Breaker (MCCB)

When the power supply voltage is too low or there is a short circuit on the input side, the circuit breaker can provide protection. When inspecting, maintaining, or not working, the circuit breaker can be disconnected to isolate the frequency converter from the power supply.

(3) Electromagnetic contactor (MC)

It facilitates the control of the inverter's power-on and power-off, ensuring safety.


(4) AC reactor (optional)

a: Suppress high harmonics and protect the frequency converter.

b: Improve power factor

(5) Braking resistor (selected)

When the motor is braking, to prevent excessive voltage in the inverter's DC circuit and improve the braking capacity of the built-in braking unit, the braking resistor connection method for the T200-BF series inverter is as follows:



Braking Resistor

2-2-2 Main Circuit Wiring Precautions

(1) Wiring specifications: Please implement wiring in accordance with electrical regulations;

(2) Do not connect AC power to the output terminals (U, V, W) of the frequency converter, otherwise it will damage the frequency converter;


(3) For power wiring, please use isolated wires and conduits as much as possible, and ground both ends of the isolated wires or conduits;

(4) The inverter grounding wire must not be grounded together with the welding machine, high-power motor or high-current load; please ground it separately.

(5) Grounding terminal E: Please ground using the third method, with a grounding impedance of less than 100Ω;

(6) When using the grounding wire, please use it in accordance with the specifications specified in the electrical equipment technical specifications. The shorter the grounding wire, the better.


(7) When multiple frequency converters are grounded, please be careful not to create a grounding loop, as shown in the figure below;



(8) The main circuit power line and control line must be wired separately. Parallel wiring should be spaced at least 10cm apart. Cross wiring should be perpendicular to each other. Do not place control line and power line in the same cable tray, otherwise it will cause interference.

(9) Under normal circumstances, the distance between the inverter and the motor should be less than 30 meters. If the distance is too long, the surge current generated by the parasitic capacitance will cause overcurrent protection and may also cause false operation, which may lead to inverter failure or abnormal equipment operation. The maximum distance between the inverter and the motor should not exceed 100 meters. If the distance is long, please select an output side filter and reduce the carrier frequency.

(10) No absorption capacitors or other RC absorption devices shall be installed on the output side (U, V, W) of the frequency converter;



(11) Please ensure that all main circuit terminals are tightened and that the leads are in good contact with the terminals to prevent loosening due to vibration, which could generate sparks and cause a short circuit;

(12) To reduce interference, it is recommended to provide electromagnetic contactors and relays in the circuits surrounding the frequency converter.

The coils of devices such as surge absorbers are connected to surge absorbers.

Recommended specifications for device 2-1-3


Inverter Model	Motor used (KW)	Main return line diameter (mm ²)	Air circuit breaker (A)	Electromagnetic contactor (A)
APV PRO-0R75G-4	0.75	0.75	6	9
APV PRO-1R5G-4	1.5	0.75	10	9
APV PRO-2R2G-4	2.2	0.75	10	9
APV PRO-3R7G-4	3.7	1.5	16	12
APV PRO-5R5G-4	5.5	2.5	20	18
APV PRO-7R5G-4	7.5	4	32	25
APV PRO-11G-4	11	4	40	32

*The data in the table above is for reference only.

2-1-4 Main Circuit Terminals and Instructions

Users can open the top cover of the frequency converter to see the main circuit terminals.

(1) The main circuit terminals of the T200-BF series frequency converter are arranged as follows:




****Note :** The illustrations are for illustrative purposes only. If the product you order differs from the actual product, please refer to the physical item .

(2) Main circuit terminal description


name	Function Description
 PE	Grounding terminal
T1, T2, T3	Power input terminal
U, V, W	Connect a three-phase AC motor
P1, PB	Braking resistor terminals

2-2 Control loop wiring

2-2-1 Control terminal diagram



2-2-2 Control Loop Wiring Diagram



2-2-3 Control Terminal Description

Terminal name	Functional Definition Description	Remark
X1	Multi-function input terminal (forward rotation)	Multi-function input terminal Terminals X1 to X6 can be accessed via... Detailed information on pages 4.00 to 4.05 Settings, setting terminals and Valid when COM is closed
X2	Multi-function input terminal (reverse)	
X3	Multi-function input terminal (reset)	
X4	Multi-function input terminal	
X5	Multi-function input terminal	
X6	Multi-function input terminal	
COM	Numeric input public terminal	
FOV	Analog voltage/current output terminals	0~10V/0~20mA
FOC	Analog voltage/current output terminals	0~10V/0~20mA
10V	Frequency setting power supply	
GND	Common terminal of analog signal terminals	
FIV	Analog voltage/current input terminals	0~10V/0~20mA
FIC	Analog voltage/current input terminals	0~10V/0~20mA
24V	24V auxiliary power supply	
COM	Input signal common terminal	
MOA, MOB, MOC	Relay output contacts	AC250V/3A, DC30V/1A
TA, TC	Relay output contact (normally open)	AC250V/3A, DC30V/1A
RS+, RS-	RS485 communication terminal	
RGND	RS485 communication common terminal	

2-2-4 Control Panel Switch Instructions:

Switch name	Switch instructions
J5	V: FOC shorted for voltage output; I: FOC shorted for current output.
J1	V: FOV shorted for voltage output; I: FOV shorted for current output.
J2	V: FIC shorted for voltage input; I: FIC shorted for current input.
J8	V: FIV shorted for voltage input; I: FIV shorted for current input.

J9/J19	When switching between STO and terminal functions, the terminal function can be edited when the jumper is in X3/X4. When the jumper is in STO1/STO2, X3/X4 only functions as STO.
J6	NPN/PNP as a low-level and high-level selector switch
J3	For RS485 communication terminating resistor selection switches, the ON side has a 120Ω resistor connected in parallel between RS+ and RS-, while the OFF side has no parallel terminating resistor between RS+ and RS-.
J4	The CAN communication terminating resistor selection switch has a 120Ω resistor connected in parallel on the ON side of the CAN bus, while no parallel terminating resistor is connected on the OFF side of the CAN bus.
J7	COM to ground selection, ON for active, OFF for inactive.
J10	GND is selected for ground; ON indicates active, OFF indicates inactive.

Precautions for power distribution in control circuits:

(1) Please separate the control signal line from the main return line and other power lines and power supply lines.

) To prevent malfunctions caused by interference, please use twisted shielded wire or double shielded wire, with a recommended specification of 0.3 to 0.5 mm².

(3) Please determine the permissible conditions for each terminal, such as power supply, maximum permissible current, etc.


(4) Grounding terminal E should be properly grounded, and the grounding impedance should be less than 100Ω.

(5) Wiring requirements for each terminal, and correct selection of accessories such as potentiometers, voltmeters, input power supplies, etc.

(6) After completing the wiring, please check it correctly and power it on only after confirming that there are no errors.

Chapter Three Operations

3-1 Instructions for the Main Unit Operation Panel



3-1-1 Button Function Description

Key symbols	name	Function Description
	Programming key	Enter or exit via the primary menu, delete shortcut parameters
	OK button	Enter the menu screen step by step, set parameters and confirm.
	UP increment key	Increment of data or function code
	DOWN decrement key	Decreasing of data or function code
	right shift key	In the shutdown and operation display interfaces, the displayed parameters can be cycled through; when modifying parameters, the modification digits can be selected.
	Run button / Stop button / Reset button	In keyboard operation mode, this key is used to start the operation; while in operation, pressing this key can stop the operation, subject to function code P7.04; in fault alarm mode, this key can be used to reset the fault, not subject to function code P7.04.

3-1-2 Indicator Light Description

Symbolic features	Symbol content description
Hz	Frequency indicator light
A	Current indicator light
V	Voltage indicator light
F/R	Forward/Reverse Indicator Light: Light off indicates forward rotation; light on indicates reverse rotation.

3-2 Operating Procedures

3-2-1 Parameter Settings

The three-level menus are as follows:

1. Function code group number (first-level menu); e.g., "P0"
2. Function code number (second-level menu); e.g., "P0.00"
3. Function code setting value (three-level menu). Example "1"

Note: When operating in the third-level menu, you can press  or




return to the second-level menu. The difference between the two is:



pressing  saves the settings to the control panel, then returns to the second-level menu and automatically moves to the next function code; pressing PRG directly returns to the second-level menu, does not save the parameters, and remains on the current function code.

Example: An example of changing function code P1.05 from 10.00Hz to 50.00Hz.



In the third-level menu state, if the parameter does not flash, it means that the function code cannot be modified. Possible reasons include:

- 1) This function code represents a parameter that cannot be modified, such as actual detection parameters or runtime record parameters.
- 2) This function code cannot be modified while the system is running; it can only be modified after the system is stopped.

3-2-2 Fault Reset

When a frequency converter malfunctions, it will display relevant fault information. Users can reset the fault using the STOP key on the keypad or the terminal function (P4 group). After a fault reset, the frequency converter will enter standby mode. If the frequency converter is in a faulty state and the user does not reset it, the frequency converter will enter a protection mode and will not be able to operate.

3-2-3 Motor Parameter Self- Learning

1: Dynamic self-learning (P1.37=2)

When selecting the PG-free vector control operation mode, the motor's

nameplate parameters must be accurately entered. The inverter will match the standard motor parameters based on these nameplate parameters. To obtain good control performance, it is recommended to perform motor parameter self-learning. The self-learning operation steps are as follows:

First, select the keyboard command channel (P0.02 = 0) as the execution command channel.

Then please enter the following parameters according to the actual parameters of the motor:

P1.01: Rated power of the motor;

P1.02: Rated voltage of the motor;

P1.03: Rated current of the motor;

P1.04: Rated frequency of the motor;

P1.05: Rated speed of the motor.

****Note:** During the full parameter self-learning process, the motor must be disconnected from the load; otherwise, the motor parameters obtained through self-learning may be incorrect. ******

2: Static self-learning (P1.37=1)

During the self-learning of motor static parameters, it is not necessary to disconnect the motor from the load. Before the self-learning, the parameters on the motor nameplate (P1.01-P1.05) must be entered correctly. After self-learning, the stator resistance, rotor resistance, and leakage inductance of the motor will be detected. However, the mutual inductance and no-load current of the motor cannot be measured. Users can enter the corresponding values according to the motor nameplate.

3-3 Operating Status

3-3-1 Power-on Initialization

During the power-on process of the frequency converter, the system first performs initialization, and all indicator lights illuminate. After initialization is complete, the frequency converter enters standby mode.

3-3 -2 Standby

In both stop and run states, various status parameters can be displayed. The display of a parameter can be selected by binary bits using function codes P7.03 and P7.04 (running parameters) and P7.05 (stop parameters). The definition of each bit is given in the description of function codes P7.03, P7.04, and P7.05.

3-3-3 Motor Parameter Self-Learning


Please refer to the detailed description of function code P1.37 for more information.

3-3 -4 Running

In operation, there are 29 status parameters that can be selected for display, namely: operating frequency, set frequency, bus voltage, output voltage, output current, operating speed, output power, output torque, etc. Whether to display them is selected by function codes P7.03 and P7.04 bit by bit (converted to binary). Press the left and right shift keys to switch the display of the selected parameters in sequence.

3-3 -5 fault

The T200-BF series frequency converters provide various fault information. For details, please refer to the T200-BF series frequency converter faults and countermeasures.

3-4 Quick Debugging

Chapter 4 Functional Parameter Summary Table

Setting PP.00 to a non- zero value means a parameter protection password is set. In function parameter mode and user parameter change mode, the parameter menu can only be accessed after entering the correct password. To remove the password, PP.00 must be set to 0. Groups P and C are for basic function parameters, and group D is for monitoring function parameters.

The symbols in the function table are explained as follows:

“ ☆ ” : This indicates that the setting value of this parameter can be changed whether the frequency converter is in a stopped or running state;

“ ★ ” : This indicates that the setting of this parameter cannot be changed when the frequency converter is running;

“ ● ” : This indicates that the value of this parameter is the actual detection record value and cannot be changed;

“*” indicates that the parameter is a " manufacturer parameter " and can only be set by the manufacturer; user operation is prohibited.

Basic Functional Parameter Summary :

function code	name	Set range	Factory value	Change
P0 Basic Function Group				
P0.00	G / P type display	1: Type G (Constant Torque Load Model)	Model confirmed	●
P0.01	Control mode selection	0 : No PG vector control 2 : V/F control	2	★
P0.02	Command source selection	0: Keyboard command channel 1: Terminal command channel 2: Communication command channel	0	☆
P0.03	Main frequency source X selection	0: Digital setting (preset frequency P0.08 , UP/DOWN can be modified) (Power failure does not retain memory) 1: Digital settings (preset frequency P0.08 , UP/DOWN can be modified) (Power-off memory) 2: FIV 3: FIC 4: Keyboard knob 5: Retain 6: Multi-segment instructions 7: Simple PLC 8: PID 9: Communication given	0	★

APV Pro Series Frequency Inverter Instruction Manual

P0.04	Auxiliary frequency source Y selection	Same as P0.0 3 (Main frequency source X selection)	0	★
P0.05	Selection of auxiliary frequency source Y range during superposition	0: relative to the maximum frequency 1: Relative to frequency source X	0	☆
P0.06	The range of auxiliary frequency source Y during superposition	0%~150%	100%	☆
P0.07	Frequency source superposition selection	Units: Frequency source selection 0: Main frequency source X 1: Results of primary and secondary operations (The operational relationship is determined by the tens digit) 2: Switching between main frequency source X and auxiliary frequency source Y 3: Switching between the main frequency source X and the main/auxiliary operation results 4: Switching between auxiliary frequency source Y and main/auxiliary operation results Tens: Frequency source master-slave operation relationship 0: Primary + Secondary 1: Primary-Secondary 2: The maximum value of the two 3: Minimum of the two	00	☆
P0.08	Preset frequency	0.00Hz ~ Maximum frequency (P0.1 0)	50.00Hz	☆
P0.09	Direction of movement	0: Same direction 1: Opposite direction	0	☆
P0.1 0	Maximum frequency	50.00Hz ~ 600.00Hz	50.00Hz	★
P0. 1 1	Upper limit frequency source	0: P0.12 setting 1: FIV 2: FIC 3: Retain	0	★

APV Pro Series Frequency Inverter Instruction Manual

		4: Retain 5: Communication given		
P0.12	Upper limit frequency	Lower frequency limit P0.14 ~ Maximum frequency P0.10	50.00Hz	☆
P0.13	Upper limit frequency offset	0.00Hz ~ Maximum frequency P0.10	0.00Hz	☆
P0.14	Lower limit frequency	0.00Hz ~ Upper limit frequency P0.12	0.00Hz	☆
P0.15	carrier frequency	0.5kHz ~ 16.0kHz	Model confirmed	☆
P0.16	Carrier frequency varies with temperature Adjustment	0: No 1: Yes	0	☆
P0.17	Acceleration time 1	0.00s ~ 65000s	Model confirmed	☆
P0.18	Deceleration time 1	0.00s ~ 65000s	Model confirmed	☆
P0.19	acceleration/deceleration time unit	0: 1 second 1: 0.1 seconds 2: 0.01 seconds	1	★
P0.21	Auxiliary frequency source bias frequency during superposition	0.00Hz ~ Maximum frequency P0.10	0.00Hz	☆
P0.22	Frequency command resolution	2: 0.01Hz	2	★
P0.23	Digital setting frequency shutdown memory selection	0: No memory 1: Memory	0	☆
P0.25	Acceleration/deceleration time reference frequency	0: Maximum frequency (P0.10) 1: Set frequency 2: 100Hz	0	★
P0.26	Runtime frequency instructions UP/DOWN benchmark	0: Operating frequency 1: Set frequency	0	★
P0.27	Command source bundled with frequency source	Units: Operation panel command binding frequency source selection 0: No binding	0000	☆

APV Pro Series Frequency Inverter Instruction Manual

		1: Digital frequency setting 2: FIV 3: FIC 4: Retain 5: Retain 6: Multi-speed 7: Simple PLC 8: PID 9: Communication given Tens: Terminal command binding frequency source selection Hundreds: Communication command binding frequency source selection		
P1 motor parameters				
P 1. 00	Motor type	0: Ordinary asynchronous motor 1: Variable frequency asynchronous motor 2: Permanent magnet synchronous motor	Factory settings	★
P1. 01	Motor rated power	0.1kW~1000.0kW	Model confirmed	★
P1. 02	Motor rated voltage	1V~2000V	Model confirmed	★
P1. 03	Motor rated current	0.01A~655.35A (Inverter power <= 55kW)	Model confirmed	★
P1. 04	Motor rated frequency	0.01Hz to maximum frequency	Model confirmed	★
P1. 05	Motor rated speed	1rpm~65535rpm	Model confirmed	★
P1. 06	asynchronous motor stator resistance	0.001Ω~65.535Ω	Learning parameter s	★
P1. 07	asynchronous motor rotor resistance	0.001Ω~65.535Ω	Learning parameter s	★
P1. 08	Leakage inductance of asynchronous motor	0.01mH~655.35mH	Learning parameter s	★
P1. 09	asynchronous motor mutual inductance	0.1mH~6553.5mH	Learning parameter s	★

APV Pro Series Frequency Inverter Instruction Manual

P1. 10	asynchronous motor no-load current	0.01A~P1.03	Learning parameters	★
P1.16	synchronous motor stator resistance	0.001Ω~65.535Ω	Learning parameters	★
P1.17	Synchronous motor D-axis inductance	0.01mH~655.35mH	Learning parameters	★
P1.18	Synchronous motor Q-axis inductance	0.01mH~655.35mH	Learning parameters	★
P1.20	Synchronous motor back electromotive force	0.1V~6553.5V	Learning parameters	★
P1.11	Motor overload protection selection	0: Prohibited 1: Allowed	1	☆
P1.12	Motor overload protection gain	0.20~10.00	1.00	☆
P1.13	Motor overload warning coefficient	50%~100%	80%	☆
P1. 37	Self-learning selection	0: No operation 1: Static self-learning 2: Dynamic self-learning 3: Completely static self-learning 11: Static self-learning of synchronous motors 12: Synchronous Motor Dynamic Self-Learning	0	★
P2 group motor vector control parameters				
P2. 00	Speed loop proportional gain 1	1~100	20	☆
P2. 01	Velocity loop integral time 1	0.01s~10.00s	0.50s	☆
P2. 02	Switching frequency 1	0.00 ~ P2.05	5.00Hz	☆
P2. 03	Speed loop proportional gain 2	1~100	15	☆
P2. 04	Velocity loop integral time 2	0.01s~10.00s	1.00s	☆
P2. 05	Switching frequency 2	P2.02 ~ Maximum Frequency	10.00Hz	☆

APV Pro Series Frequency Inverter Instruction Manual

P2. 06	Vector control slip gain	50%~200%	100%	☆
P2. 07	Velocity loop filter time constant	0.000s ~ 1.000s	0.0 50 s	☆
P2. 08	Vector control overexcitation gain	0~200	64	☆
P2. 09	Torque upper limit source under speed control mode	0: Function code P2.10 setting (No distinction between electric and generator) 1: FIV 2: FIC 3: Retain 4: Retain 5: Communication given 6: MIN (FIV , FIC) 7: MAX(FIV , FIC) The full-scale range for options 1-7 corresponds to P2.10 .	0	☆
P2. 10	Torque upper limit digital setting under speed control mode (electric)	0.0%~200.0%	1 50.0%	☆
P2.11	Torque upper limit command selection under speed control mode (power generation)	0: Function code P2.10 setting 1: FIV 2: FIC 3: Retain 4: Retain 5: Communication given 6: MIN (FIV , FIC) 7: MAX(FIV , FIC) 8: Function code P2.12 setting The full-scale range for options 1-7 corresponds to P2. 1 2	0	☆
P2.12	Torque upper limit digital setting under speed control mode (power generation)	0.0%~200.0%	1 50.0%	☆
P2. 13	Excitation regulation proportional gain	0~60000	2000	☆
P2. 14	Excitation regulation integral	0~60000	1300	☆

APV Pro Series Frequency Inverter Instruction Manual

	gain			
P2. 15	Torque regulation proportional gain	0~60000	2000	☆
P2. 16	Torque regulation integral gain	0~60000	1300	☆
P2. 17	Speed ring integral attribute	Units digit: Separation of integrals 0: Invalid 1: Effective	0	☆
P2. 21	Maximum torque coefficient in the weak magnetic region	10 % ~ 500 %	100%	☆
P2.22	Power generation limit enable	0: Invalid 1: Effective throughout	0	☆
P2.23	upper limit of power generation	1 % ~ 50%	5%	☆
P2.24	Synchronous machine initial position detection current	50 % ~ 180%	120%	
P2.25	Synchronizer initial position angle detection	0 (Check every time it runs) 1 (Not tested) 2 (First run test after power-on)	0	
P2.27	Synchronous machine saliency rate adjustment gain	50~500	100	
P2.28	Maximum torque-current ratio control	0 (Not enabled), 1 (Enabled)	0	
P2.36	Synchronous machine low-speed excitation current	0% ~ 80%	30%	
P2.37	Start carrier frequency	0.8kHz ~ P0.15	4	
P2.42	Synchronous machine speed tracking	0 (Not enabled), 1 (Enabled)	0	
P2.43	Zero Servo Enable	0 (Not enabled), 1 (Enabled)	0	
P2.44	Switching frequency	0.00~P2.02	0.30	
P2.45	Zero servo speed	1~100	10	

APV Pro Series Frequency Inverter Instruction Manual

	loop proportional gain			
P2.46	Zero servo speed loop integral time	0.01s ~ 10.00s	0.50	
P2.47	Stopping machine and preventing reverse rotation	0 (Not enabled) 1 (On) (To prevent the motor from reversing when decelerating to 0Hz)	0	
P2.48	Stop angle	0.0°~10.0° (This value should be increased appropriately if reversal still occurs under factory conditions)	0.8°	
P2.49	Tuning-free mode	0: Not enabled 1: Power-on test once 2: Always turn on	0	
P2.50	Online back EMF calculation	0: Not calculated 1: Calculation	0	
P3 group V/F control parameters				
P3. 00	VF curve setting	0: Linear V/F 1: Multi-point V/F 2: Square V/F 3:1.2 V/F 4:1.4 V/F 6:1.6 V/F 8:1.8 V/F 9: Retain 10: VF Fully Separated Mode 11: VF Semi-Separation Mode	0	★
P3.01	Torque boost	0.0%: (Automatic torque boost) 0.1%~30.0%	Model confirmed	☆
P3. 02	Torque boost cutoff frequency	0.00Hz to maximum frequency	50.00Hz	★
P3.03	Multi-point VF frequency point 1	0.00Hz ~ P3.05	0.00Hz	★
P3. 04	Multi-point VF voltage point 1	0.0%~100.0%	0.0%	★
P3. 05	Multi-point VF frequency point 2	Pages 3.03 to 3.07	0.00Hz	★
P3. 06	Multi-point VF voltage point 2	0.0%~100.0%	0.0%	★
P3. 07	Multi-point VF frequency point 3	P3.05 ~ Rated frequency of the motor (P1.04)	0.00Hz	★
P3. 08	Multi-point VF	0.0%~100.0%	0.0%	★

APV Pro Series Frequency Inverter Instruction Manual

	voltage point 3			
P3. 09	VF slip compensation gain	0.0%~200.0%	0.0%	☆
P3. 10	VF overexcitation gain	0~200	64	☆
P3. 11	VF oscillation suppression gain	0~100	Model confirmed	☆
P3. 13	VF-separated voltage source	0: Numerical setting (P3.14) 1: FIV 2: FIC 3: Retain 4: Retain 5: Multi-segment instructions 6: Simple PLC 7: PID 8: Communication given Note: 100.0% corresponds to the rated voltage of the motor.	0	☆
P3. 14	VF-separated voltage digital setting	0V ~ Motor rated voltage	0V	☆
P3. 15	VF separation voltage acceleration time	0.0s~1000.0s Note: This indicates the time it takes for the voltage to change from 0V to the motor's rated voltage.	0.0s	☆
P3.1 6	VF deceleration time	0.0s~1000.0s Note: This indicates the time it takes for the motor's rated voltage to change to 0V.	0.0s	☆
P3.17	VF disconnection shutdown method selection	0: Frequency/voltage independently reduced to 0 1: After the voltage is reduced to 0, the frequency is then reduced.	0	☆
P3.18	Overcurrent tripping current	50%~200%	150%	★
P3.19	Overcurrent speed enable	0: Invalid 1: Valid	1	★
P3.20	Overflow rate suppression gain	0~100	20	☆
P3.21	Double speed over-speed deceleration	50%~200%	50%	★

APV Pro Series Frequency Inverter Instruction Manual

	operating current compensation coefficient			
P3.22	Overvoltage stall operating voltage	650.0V~800.0V	7 6 0.0V	★
P3.23	Overvoltage stall enable	0: Invalid 1: Valid	1	★
P3.24	Overvoltage stall suppression frequency gain	0~100	30	☆
P3.25	Overvoltage stall suppression voltage gain	0~100	30	☆
P3.26	Maximum rise frequency limit of overvoltage stall	0~50Hz	5Hz	★
P4 group input terminals				
P4. 00	X 1 terminal function selection	0: No function 1: Forward Rotation (FWD) 2: Reverse operation (REV) 3: Three-wire operation control 4: Forward jogging (JOG F) 5: Reverse Jog (JOG R) 6: Terminal UP 7: Terminal DOWN 8: Free Parking 9: Fault Reset (RESET) 10: Operation paused 11: Normally open input for external faults 12: Multi-segment instruction terminal 1 13: Multi-segment instruction terminal 2 14: Multi-segment instruction terminal 3 15: Multi-segment instruction terminal 4 16: Acceleration/deceleration time selection terminal 1 17: Acceleration/deceleration time selection terminal 2 18: Frequency source switching 19: Reset UP/DOWN settings (Terminals, Keyboard)	0	★
P4. 01	X 2 terminal function selection		0	★
P4. 02	X 3 terminal function selection		9	★
P4. 03	X 4 terminal function selection		12	★
P4. 04	X 5 terminal function selection		13	★
P4. 05	X 6 terminal function selection		0	★
P4.06	reserve		2	★
P4.07	reserve		1	★

		20: Run command to switch terminals 21: Acceleration and deceleration prohibited 22: PID pause 23: PLC Status Reset 24-28 : Reserved 29: Torque control disabled 30: Retain 31: Retain 32: Immediate DC braking 33: Normally closed input for external faults 34: Frequency Modification Enable 35: Reverse the direction of PID control 36: External parking terminal 1 37: Control command switching terminal 2 38: PID Integral Pause 39: Switching between frequency source X and preset frequency 40: Frequency source Y and preset frequency switching 41 ~42 : Retain 43: PID Parameter Switching 44 ~45 : Retain 46: Speed control/torque control switching 47: Emergency Stop 48: External parking terminal 2 49: Deceleration DC Braking 50: This run time is reset to zero. 5.1 : Pump 1 is ineffective . 5.2 : Pump 2 is ineffective . 53 : Pump 3 is ineffective. 54 : Pump 4 is ineffective. 5.5-59 : Reserved 62: No water alarm		
P4. 10	Switching quantity filtering time	0.000s~1.000s	0.010s	☆
P4. 11	Terminal	0: Two-line type 1	0	

APV Pro Series Frequency Inverter Instruction Manual

	command method	1: Two-line type 2 2: Three-line type 1 3: Three-line type 2		★
P4. 12	Terminal UP/DOWN change rate	0.001Hz/s~65.535Hz/s	1.00Hz/s	☆
P4. 13	FI curve 1 minimum input	0.00V~ P4. 15	0.00V	☆
P4. 14	FI curve 1 minimum input corresponding setting	-100.0%~+100.0%	0.0%	☆
P4. 15	FI curve 1 Maximum input	P4. 13~+10.00V	10.00V	☆
P4. 16	FI curve 1 maximum input corresponding setting	-100.0%~+100.0%	100.0%	☆
P4. 17	FI curve 1 filter time	0.00s~10.00s	0.10s	☆
P4. 18	FI curve 2 minimum input	0.00V~ P4. 20	0.00V	☆
P4. 19	FI curve 2 minimum input corresponding settings	-100.0%~+100.0%	0.0%	☆
P4. 20	FI curve 2 maximum input	P4. 18~+10.00V	10.00V	☆
P4. 21	FI curve 2 maximum input corresponding setting	-100.0%~+100.0%	100.0%	☆
P4. 22	FI curve 2 filter time	0.00s~10.00s	0.10s	☆
P4. 23	FI curve 3 minimum input	-10.00V~ P4. 25	-10.00V	☆
P4. 24	FI curve 3 minimum input corresponding settings	-100.0%~+100.0%	-100.0%	☆
P4. 25	FI curve 3 Maximum input	P4. 23~+10.00V	10.00V	☆
P4. 26	FI curve 3 maximum input corresponding	-100.0%~+100.0%	100.0%	☆

	settings			
P4. 27	FI curve 3 filtering time	0.00s~10.00s	0.10s	☆
P4. 33	FI curve selection	Units: FIV curve selection 1: Curve 1 (2 points, see pages 4.13 to 4.16) 2: Curve 2 (2 points, see pages 4.18 to 4.21) 3: Curve 3 (2 points, see pages 4.23-4.26) 4: Curve 4 (4 points, see C6.00~C6.07) 5: Curve 5 (4 points, see C6.08~C6.15) Tens: FIC curve selection, same as above. Hundreds: Reserved	321	☆
P4. 34	FI below minimum input setting selection	Units digit: FIV is below the minimum input setting selection. 0: Corresponds to the minimum input setting of 1: 0.0%. Tens: FIC is selected below the minimum input setting, same as above.	000	☆
P4. 35	X 1 delay time	0.0s~3600.0s	0.0s	★
P4. 36	X 2 delay time	0.0s~3600.0s	0.0s	★
P4. 37	X 3 delay time	0.0s~3600.0s	0.0s	★
P4. 38	X- terminal active mode Choose 1	0: High level is active 1: Active low Units digit: X 1 Tens digit: X 2 Hundreds digit: X 3 Thousands: X 4 Tens of thousands place: X 5	00000	★
P4. 39	S- Terminal Active Mode Option 2	0: High level is active 1: Active low Units digit: X6 Tens: Reserved Hundreds: Reserved Thousands: Reserved Ten thousandths place: reserved	00000	★
P5 group output terminals				

APV Pro Series Frequency Inverter Instruction Manual

P5.01	Control board relay function selection (MOA-MOB-MOC)	0: No output 1: Inverter in operation 2: Fault Output 3: Frequency level detection FDT1 output 4: Frequency arrives 5: Running at zero speed (No output when the machine is stopped) 6: Motor overload warning	0	☆
P5.0 2	Control board relay function selection (TA -- TC)	7: Inverter overload pre-alarm 8: Retain 9: Retain 10: Length reached 11: PLC cycle complete 12: Cumulative running time reached 13: Frequency limited 14: Torque Limiting 15: Ready to run 16: FIV > FIC 17: Maximum frequency reached 18: Lower limit frequency reached (Related to operation) 19: Undervoltage output 20: Communication Settings 21: (Reserved) 22: (Reserved) 23: Running at zero speed 2 (Also outputting during shutdown) 24: Cumulative power-on time reached 25: Frequency Level Detection FDT2 Output 26: Frequency 1 reaches output 27: Frequency 2 reaches output 28: Current 1 reaches the output 29: Current 2 reaches the output 30: Timed arrival output 31: FIV input limit exceeded 32: Loading 33: Running in reverse	0	☆

APV Pro Series Frequency Inverter Instruction Manual

		34: Zero current state 35: Module temperature reached 36: Output current exceeds limit 37: Lower limit frequency reached (Output even when the machine is stopped) 38: Alarm Output (Continue Running) 39: Motor over-temperature warning 40: This run has ended. 41: Fault output (no output under low voltage)		
P5. 07	FOV output function selection	0: Operating frequency 1: Set frequency 2: Output current 3: Output torque 4: Output power 5: Output voltage 6: Retain 7: FIV	0	☆
P5. 08	FOC output function selection	8: FIC 9 ~11 : Reserved 12: Communication Settings 13: Motor speed 14: Output current (100.0% corresponds to 1000.0A) 15: Output voltage (100.0% corresponds to 1000.0V) 16: Motor output torque (actual value, percentage relative to the motor)	1	☆
P5. 10	FOV zero bias coefficient	-100.0% ~ +100.0%	0.0%	☆
P5. 11	FOV gain	-10.00 to +10.00	1.00	☆
P5. 12	FOC zero-bias coefficient	-100.0% ~ +100.0%	0.0%	☆
P5. 13	FOC gain	-10.00 to +10.00	1.00	☆
P5.15	FOV output filtering time	0.00s~10.00s	0.01s	☆
P5.16	FOC output filtering time	0.00s~10.00s	0.01s	☆
P5.17	MOA-MOB-MOC output delay time	0.0s ~ 3600.0s	0.0s	★

APV Pro Series Frequency Inverter Instruction Manual

P5. 18	T A- T C output delay time	0.0s~3600.0s	0.0s	☆
P5. 19	reserve	0.0s~3600.0s	0.0s	☆
P5. 22	Output terminal valid state selection	0: Positive logic 1: Anti-logic Units digit: MOA-MOB-MOC Tens: TA-TC Hundreds: Reserved	00000	☆
P6 Start/Stop Parameter Group				
P6. 00	Startup method	0: Start directly	0	☆
P6.01	Speed tracking method	0: Starting from the downtime frequency 1: Start from zero speed 2: Start from the highest frequency	0	★
P6. 02	Speed tracking speed	1~100	20	☆
P6. 03	Startup frequency	0.00Hz~10.00Hz	0.00Hz	☆
P6. 04	Startup frequency retention time	0.0s~100.0s	0.0s	★
P6. 05	Starting DC braking current/pre-excitation current	0%~100%	0%	★
P6. 06	DC braking time/pre-excitation time	0.0s~100.0s	0.0s	★
P6. 07	Acceleration and deceleration methods	0: Linear acceleration/deceleration 1: S-curve acceleration/deceleration A 2: Dynamic S-curve acceleration and deceleration	0	★
P6. 08	The proportion of the initial period of the S-curve	0.0%~ (100.0%- P6. 09)	30.0%	★
P6. 09	The proportion of the time segment ending the S-curve	0.0%~(100.0%- P6. 08)	30.0%	★
P6. 10	Shutdown methods	0: Decelerate and stop; 1: Free stop	0	☆
P6. 11	DC braking start frequency during shutdown	0.00Hz to maximum frequency	0.00Hz	☆

APV Pro Series Frequency Inverter Instruction Manual

P6. 12	DC braking waiting time during shutdown	0.0s~100.0s	0.0s	☆
P6. 13	DC braking current during shutdown	0%~100%	0%	☆
P6. 14	DC braking time during shutdown	0.0s~100.0s	0.0s	☆
P6. 15	Brake utilization	0%~100%	100%	☆
P6.18	Rotational speed tracking current magnitude	30%~200%	Model confirmed	★
P6.21	Demagnetization time (SVC is effective)	0.00~5.00s	Model confirmed	☆
P7 Keyboard and Display				
P7.01	JOG Functional Parameters	0: This key has no function. 1: Switch between external keyboard commands and remote operation. This refers to switching the command source, i.e., switching between the current command source and keyboard control (local operation). If the current command source is keyboard control, this key function is invalid. 2: Switch between forward and reverse directions using the JOG key. This function is only available when the command source is the operation panel command channel. 3: Forward jogging is achieved by pulling out the JOG key on the keyboard (JOG-FWD). 4: Reverse motion is achieved by pulling out the JOG key on the keyboard (JOG-REV). 5: Start/Stop buttons can be selected separately (6 buttons)	0	★
P7.02	STOP/RESET button function	RESET key stop function is only effective in keyboard operation mode. 1. The STOP/RESET button's	1	☆

		stop function is effective in any operating mode .		
P7.03	LED Operation Display Parameter 1	0000~FFFF Bit00: Operating frequency 1 (Hz) Bit01: Set frequency (Hz) Bit02: Bus voltage (V) Bit03: Output Voltage (V) Bit04: Output Current (A) Bit05: Output power (kW) Bit06: Output Torque (%) Bit07: DI Input Status Bit08: DO output status Bit09: FIV Voltage (V) Bit10: FIC voltage (V) Bit11: Reserved Bit12: Reserved Bit13: Reserved Bit14: Load speed display Bit15: PID setting	1F	☆
P7.04	LED Operation Display Parameter 2	0000~FFFF Bit00: PID input and feedback Bit01: PLC Stage Bit02: Reserved Bit03: Operating frequency 2 (Hz) Bit04: Remaining runtime Bit05: Voltage before FIV correction (V) Bit06: Voltage before FIC correction (V) Bit07: Reserved Bit08: Motor speed Bit09: Current power-on time (Hour) Bit10: Current running time (Min) Bit11: Reserved Bit12: Communication settings Bit13: Reserved Bit 14: Main frequency X display (Hz) Bit 15: Secondary frequency Y display (Hz)	0	☆
P7.05	LED stop display parameters	0000~FFFF Bit00: Set frequency (Hz)	33	☆

APV Pro Series Frequency Inverter Instruction Manual

		Bit01: Bus voltage (V) Bit02: DI Input Status Bit03: DO output status Bit04: FIV voltage (V) Bit05: FIC voltage (V) Bit06: Reserved Bit07: Reserved Bit08: Reserved Bit09: PLC Stage Bit10: Load speed Bit11: PID setting Bit12: Reserved Bit 1 3 : PID Command and Feedback		
P7. 06	Load speed display coefficient	0.0001~6.5000	1.0000	☆
P7. 07	Inverter module heatsink temperature	0.0°C~1 2 0.0°C	-	●
P7.09	Cumulative running time	0h~65535h	-	●
P7.11	Software version	-	-	●
P7.12	Load speed display decimal places	Units digit: D0.14 Number of decimal points 0: 0 decimal places 1: 1 decimal place 2: 2 decimal places 3: 3 decimal places	1	☆
P7.13	Total power-on time	0h~65535h	-	●
P7.14	Cumulative power consumption	0kW~65535 degrees	-	●
P8 group accessibility functions				
P8. 00	Jog operation frequency	0.00Hz to maximum frequency	2.00Hz	☆
P8. 01	Inching acceleration time	0.0s~6500.0s	20.0s	☆
P8. 02	Inching deceleration time	0.0s~6500.0s	20.0s	☆
P8. 03	Acceleration Time 2	0.00 s ~65000s	Model confirmed	☆
P8. 04	Deceleration time 2	0.0s~65000s	Model confirmed	☆

APV Pro Series Frequency Inverter Instruction Manual

P8. 05	Acceleration Time 3	0.0s~65000s	Model confirmed	☆
P8. 06	Deceleration time 3	0.0s~65000s	Model confirmed	☆
P8. 07	Acceleration Time 4	0.0s~65000s	Model confirmed	☆
P8. 08	Deceleration time 4	0.0s~65000s	Model confirmed	☆
P8. 09	Jump frequency 1	0.00Hz to maximum frequency	0.00Hz	☆
P8. 10	Jump frequency 2	0.00Hz to maximum frequency	0.00Hz	☆
P8. 11	Jump frequency amplitude	0.00Hz to maximum frequency	0.01Hz	☆
P8. 12	Forward and reverse dead zone time	0.0s~3000.0s	0.0s	☆
P8. 13	Invert control enable	0: Allowed 1: Prohibited	0	☆
P8. 14	Setting the operating frequency to below the lower limit	0: Operating at the following frequency limit 1: Shutdown 2: Zero-speed operation	0	☆
P8. 15	Sagging control	0.00Hz~10.00Hz	0.00Hz	☆
P8. 16	Set cumulative power-on arrival time	0h~65000h	0h	☆
P8. 17	Set cumulative running time	0h~65000h	0h	☆
P8. 18	Start Protection Selection	0: No protection 1: Protection	0	☆
P8. 19	Frequency Detection Value (FDT1)	0.00Hz to maximum frequency	50.00Hz	☆
P8. 20	Frequency Detection Lag (FDT1)	0.0%~100.0% (FDT1 level)	5.0%	☆
P8. 21	Frequency reaches detection width	0.0%~100.0% (maximum frequency)	0.0%	☆
P8. 22	Is the jump frequency effective during acceleration and deceleration?	0: Invalid 1: Valid	0	☆
P8. 25	Acceleration Time	0.00Hz to maximum frequency	0.00Hz	☆

APV Pro Series Frequency Inverter Instruction Manual

	1 and Acceleration Time 2 switching frequency points			
P8. 26	Frequency switching point between deceleration time 1 and deceleration time 2	0.00Hz to maximum frequency	0.00Hz	☆
P8. 27	Terminal inching priority	0: Invalid 1: Valid	0	☆
P8. 28	Frequency Detection Value (FDT2)	0.00Hz to maximum frequency	50.00Hz	☆
P8. 29	Frequency Detection Lag (FDT2)	0.0%~100.0% (FDT2 level)	5.0%	☆
P8. 30	Arbitrary arrival frequency detection value 1	0.00Hz to maximum frequency	50.00Hz	☆
P8. 31	Arbitrary arrival frequency detection width 1	0.0%~100.0% (maximum frequency)	0.0%	☆
P8. 32	Arbitrary arrival frequency detection value 2	0.00Hz to maximum frequency	50.00Hz	☆
P8. 33	Arbitrary arrival frequency detection width 2	0.0%~100.0% (maximum frequency)	0.0%	☆
P8. 34	Zero current detection level	0.0%~300.0% 100.0% corresponds to the motor's rated current	5.0%	☆
P8. 35	Zero current detection delay time	0.01s~600.00s	0.10s	☆
P8. 36	Output current exceeds limit	0.0% (Not detected) 0.1%~300.0% (motor rated current)	200.0%	☆
P8. 37	Output current over-limit detection delay time	0.00s~600.00s	0.00s	☆
P8. 38	Arbitrary arrival current 1	0.0%~300.0% (motor rated current)	100.0%	☆
P8. 39	Arbitrary arrival	0.0%~300.0% (motor rated	0.0%	☆

APV Pro Series Frequency Inverter Instruction Manual

	current 1 width	current)		
P8. 40	Arbitrary arrival current 2	0.0%~300.0% (motor rated current)	100.0%	☆
P8. 41	Arbitrary arrival current 2 width	0.0%~300.0% (motor rated current)	0.0%	☆
P8. 42	Timer function selection	0: Invalid 1: Effective	0	☆
P8. 43	Scheduled run time selection	0: P8.44 settings 1: FIV 2: FIC 3: Retain The analog input range corresponds to page 8.44.	0	☆
P8. 44	Scheduled run time	0.0 Min~6500.0 Min	0.0Min	☆
P8. 45	FIV Input Voltage Protection Lower Limit	0.00V ~ P8.46	3.10V	☆
P8. 46	FIV Input Voltage Protection Upper Limit	P8. 45~10.00V	6.80V	☆
P8. 47	Module temperature reached	0°C~100°C	75°C	☆
P8. 48	Cooling fan control	0: Fan operates during operation 1: The fan keeps running.	0	☆
P8. 49	wake-up frequency	Sleep frequency (P8.51) ~ Maximum frequency (P0.1 0)	0.00Hz	☆
P8. 50	Wake-up delay	0.0s~6500.0s	0.0s	☆
P8. 51	Sleep frequency	0.00Hz ~ Wake-up frequency (P8.49)	0.00Hz	☆
P8. 52	hibernation delay time	0.0s~6500.0s	0.0s	☆
P8. 53	Arrival time setting for this run	0.0 Min~6500.0 Min	0.0Min	☆
P8.54	Output power correction factor	0~200%	100%	☆
P8.55	Rapid deceleration time	0~6553.5s	Model confirmed	☆
P9 Group Faults and Protection				
P9. 03	Overvoltage stall gain	0~100	3 0	☆
P9. 04	Overvoltage stall	200.0V ~ 2200.0V	760.0V	☆

APV Pro Series Frequency Inverter Instruction Manual

	protection voltage			
P9. 07	Power-on short-circuit protection selection	0: Invalid 1: Valid	1	☆
P9. 09	Number of automatic fault resets	0~20	0	☆
P9. 10	Fault YO Action Selection During Automatic Fault Reset	0: No action 1: Actions	0	☆
P9. 11	Automatic fault reset interval	0.1s~100.0s	1.0s	☆
P9. 12	Input phase loss /contactor engagement protection selection	Units digit: Input phase loss protection selection Tens: Contactor pull-in protection selection 0: Prohibited 1: Allowed	00	☆
P9. 13	Output phase loss protection selection	0: Prohibited 1: Allowed Units digit: Output phase loss protection selection Tens digit: Select phase loss protection before operation.	1	☆

APV Pro Series Frequency Inverter Instruction Manual

P9. 14	First type of failure	0: No fault 1: Retain 2: Accelerate overcurrent 3: Deceleration overcurrent 4: Constant speed overcurrent 5: Accelerating overvoltage 6: Deceleration overvoltage 7: Constant speed overvoltage 8: Buffer resistor overload 9: Undervoltage 10: Inverter overload 11: Motor overload 12: Input phase loss 13: Output phase loss 14: Module overheating 15: External Fault 16: Communication error 17: Contactor malfunction 18: Current detection abnormality 19: Motor self-learning abnormality 20: Retain		•
P9. 15	Second type of failure	21: Parameter read/write exception 22: Inverter hardware malfunction 23: Motor short circuit to ground 24 : Low water pressure alarm 25: Retain 26: Running time reached 27 : High water pressure alarm 28 : Water shortage alarm 29 : Power-on time has arrived. 30: Loadout	-	•
P9. 16	Third (most recent) fault type	31: PID feedback lost during runtime 40: Fast rate limiting timeout 41: Switching motors during operation 42 : Speed deviation is too large 43: Motor overspeed 45: Motor overheating 51: Initial position error	-	•
P A group PID function				

APV Pro Series Frequency Inverter Instruction Manual

PA.00	PID given source	0: PA.01 settings 1: FIV 2: FIC 3: Retain 4: Retain 5: Communication given 6: Multi-segment instruction setting	0	☆
PA.01	Set pressure	0.00 bar ~ PA.04	3.0 0	☆
PA.02	PID feedback source	0: FIV 1: FIC 2: Retain 3: FIV-FIC 4: Retain 5: Communication given 6: FIV+FIC 7: MAX(FIV , FIC) 8: MIN (FIV , FIC)	1	☆
PA.03	PID direction of action	0: Positive effect 1: Reaction	0	☆
PA.04	Pressure range	0 ~ 65 0.00 bar	10.00	☆
PA.05	Proportional gain Kp1	0.0 ~ 600.0	20 0.0	☆
PA.06	Integration Time Ti1	0.01s~10.00s	2.00s	☆
PA.07	Differential time Td1	0.000s~10.000s	0.000s	☆
PA.08	PID reverse cutoff frequency	0.00 ~ Maximum frequency	0.00Hz	☆
PA.09	PID Deviation Limit	0.0%~100.0%	0.3 %	☆
PA.10	PID derivative limiting	0.00%~100.00%	0.10%	☆
PA.11	PID given change time	0.00~650.00s	0.00s	☆
PA.12	PID feedback filter time	0.00~60.00s	0.00s	☆
PA.13	PID output filtering time	0.00~60.00s	0.00s	☆
PA.14	reserve	-	-	☆
PA.15	Proportional gain	0.0 ~ 600.0	3 00.0	☆

APV Pro Series Frequency Inverter Instruction Manual

	Kp2			
PA.16	Integration Time Ti2	0.01s~10.00s	0.50s	☆
PA.17	Differential time Td2	0.000s~10.000s	0.000s	☆
PA.18	PID parameter switching conditions	0: Do not switch 1: Switch via X-terminal 2: Automatic switching based on deviation 3: Automatic switching based on operating frequency	2	☆
PA.19	PID parameter switching deviation 1	0.0%~PA.20	5.0%	☆
PA.20	PID parameter switching deviation 2	PA. 19~100.0%	10.0%	☆
PA.21	PID initial value	0.0%~100.0%	0.0%	☆
PA.22	PID initial value hold time	0.00~650.00s	0.00s	☆
PA.23	Maximum positive deviation between two outputs	0.00%~100.00%	2.00%	☆
PA.24	The maximum value of the opposite deviation between the two outputs	0.00%~100.00%	2.00%	☆
PA.25	PID integral attribute	Units digit: Separation of integrals 0: Invalid 1: Effective Tens digit: Whether to stop integrating after the output reaches the limit. 0: Continue accumulating points 1: Stop scoring	00	☆
PA.26	PID feedback loss of detection value	0.0%: No feedback loss is detected. 0.1%~100.0%	0.0%	☆
PA.27	PID feedback loss detection time	0.0s~20.0s	1.0s	☆

APV Pro Series Frequency Inverter Instruction Manual

PA.28	PID Stop Calculation	0: No operation during shutdown 1: Operations during shutdown	0	☆
PA.29	Sleep frequency	0.00~Maximum frequency	25.00HZ	☆
PA.30	hibernation time	0.00~6000 0 S	10S	☆
PA.31	Sleep wake-up value	0.00~PA.0 1 If the pressure is PA.31 lower than the target pressure while the device is in hibernation, it will be awakened.	0.50	☆
PA.32	Upper limit alarm value for feedback signal (e.g., high pressure).	PA.33~PA.04	8.00	☆
PA.33	Feedback signal lower limit alarm value: Setting it to 0 will disable the alarm.	0.00~PA.32	0	☆
PA.34	Water pressure test value	0.00 ~ PA.01	0.25	☆
PA.35	After the pressure returns to normal, the high-pressure or low-pressure fault will be automatically cleared after a delay of PA.35.	0~9999S	10S	☆
PA.36	Low-voltage alarm detection time	0~9999S	10S	☆
PA.37	Water shortage alarm detection time	0~9999S	100S	☆
PA.38	Automatic operation upon power-on	0~1 (0: does not run automatically upon power-on)	0	☆
PA.39	Water shortage self-reset interval	0~65000S	60s	☆
PA.40	Number of times the water pressure self-reset is insufficient	0~65000	10	☆
PA.41	Antifreeze	0~1	0	☆

APV Pro Series Frequency Inverter Instruction Manual

	effective: 1 - effective, 0 - ineffective			
PA.42	Hibernation, antifreeze waiting time	0~65 535 s	900s	☆
PA.43	Hibernation, anti- freeze operation time	0~65 535 s	30s	☆
PA.44	During hibernation, antifreeze operation frequency	0~50.00Hz	15.00 HZ	☆
PA.45	Sleep mode detection: Sleep mode detection only begins when the frequency change is < PA . 4 5 / s .	0~10.00Hz	0.50HZ	☆
PA.46	Hibernation Detection: Pressure to reduce frequency throttling	0.0~10.0%	0.6%	☆
PA.47	Hibernation Detection: Frequency of decrease per second	0~10.00Hz	1.00HZ	☆
PA.48	Hibernation detection: the number of times the frequency of descent is measured.	0~1000	10 times	☆
PA.49	Sleep detection: If the frequency is greater than PA.49, sleep is not detected.	0~Maximum frequency P0.10	42.00HZ	☆
PA.50	P ID sampling time	0~1000 ms	4ms	☆
PA.51	Pump frequency	0.00~Maximum frequency	49.00Hz	

APV Pro Series Frequency Inverter Instruction Manual

PA.52	Pump testing time	0.0~6553.5s	10.0s	
PA.53	Reduce pump frequency	0.00~Maximum frequency	25.00Hz	
PA.54	Reduce pump detection time	0.0~6553.5s	10.0s	
PA.55	Pump replacement time	0.0~65535 minutes	1 20 minutes	
PA.56	Contactor engagement delay time	0.1~100.0s	1.0 s	
PA.57	Contactor disconnection delay time	0.1~100.0s	1.0 s	
PA.58	Effective selection of each pump	0: Invalid 1: Effective Units digit: Pump No. 1 Tens: Pump No. 2 Hundreds: Pump No. 3 Thousands: Pump No. 4	11	
PA.59	Multi-pump function is effective	0: Standard machine 1: Retain 2. Multi-pump communication: One master unit, multiple slave units	0	
PA.62	main pump	1: Main pump, 0: Slave pump	0	
PA.63	Replacing the variable frequency pump is effective during startup.	0: Invalid 1: Effective	0	
PA.64	Maximum number of operating pumps	Range 1~4	4	
PA.65	Faulty main pump enable	0: Off 1: On	0	
PA.66	Backup main pump operation command source	0: Keyboard 1: terminal 2: Communication	0	
PA.67	PID display mode	1: Feedback P XX.X Target H XX.X 2: Left target, right feedback	2	
PA.68	Vibration feedback selection	0: FIV 1: FIC	0	
PA.69	Vibration alarm percentage	0.0%~100.0% (4~20mA percentage)	0 0% (Fault	

APV Pro Series Frequency Inverter Instruction Manual

		0.0% indicates that the vibration alarm function is off.	code SE)	
PC group multi-segment instruction, simple PLC				
PC. 00	Multi-segment instruction 0	-100.0% ~ 100.0%	0.0%	☆
PC. 01	Multi-segment instruction 1	-100.0% ~ 100.0%	0.0%	☆
PC. 02	Multi-segment instruction 2	-100.0% ~ 100.0%	0.0%	☆
PC. 03	Multi-segment instruction 3	-100.0% ~ 100.0%	0.0%	☆
PC. 04	Multi-segment instruction 4	-100.0% ~ 100.0%	0.0%	☆
PC. 05	Multi-segment instruction 5	-100.0% ~ 100.0%	0.0%	☆
PC. 06	Multi-segment instruction 6	-100.0% ~ 100.0%	0.0%	☆
PC. 07	Multi-segment instruction 7	-100.0% ~ 100.0%	0.0%	☆
PC. 08	Multi-segment instruction 8	-100.0% ~ 100.0%	0.0%	☆
PC. 09	Multi-segment instruction 9	-100.0% ~ 100.0%	0.0%	☆
PC. 10	Multi-segment instruction 10	-100.0% ~ 100.0%	0.0%	☆
PC. 11	Multi-segment instruction 11	-100.0% ~ 100.0%	0.0%	☆
PC. 12	Multi-segment instruction 12	-100.0% ~ 100.0%	0.0%	☆
PC. 13	Multi-segment instruction 13	-100.0% ~ 100.0%	0.0%	☆
PC. 14	Multi-segment instruction 14	-100.0% ~ 100.0%	0.0%	☆
PC. 15	Multi-segment instruction 15	-100.0% ~ 100.0%	0.0%	☆
PC. 16	Simplified PLC Operation Mode	0: Shutdown after a single run 1: Retain final value after a single run 2: Keep looping	0	☆
PC. 17	Simple PLC power-off memory selection	Units: Power-off memory selection 0: No memory after power failure 1: Power-off memory	00	☆

APV Pro Series Frequency Inverter Instruction Manual

		Tens: Stop memory selection 0: No memory of shutdown 1: Shutdown memory		
PC. 18	Simple PLC segment 0 running time	0.0s(h)~65 00. 0s (h)	0.0s (h)	☆
PC. 19	Simple PLC Stage 0 Acceleration/Decel eration Time Selection	0~3	0	☆
PC. 20	Simple PLC first stage running time	0.0s(h)~65 00. 0s (h)	0.0s (h)	☆
PC. 21	Simple PLC Stage 1 Acceleration/Decel eration Time Selection	0~3	0	☆
PC. 22	Simplified PLC second stage running time	0.0s(h)~65 00. 0s (h)	0.0s (h)	☆
PC. 23	Simple PLC Second Stage Acceleration/Decel eration Time Selection	0~3	0	☆
PC. 24	Simplified PLC third segment running time	0.0s(h)~65 00. 0s (h)	0.0s (h)	☆
PC. 25	Simple PLC Stage 3 Acceleration/Decel eration Time Selection	0~3	0	☆
PC. 26	Simplified PLC running time, segment 4	0.0s(h)~65 00. 0s (h)	0.0s (h)	☆
PC. 27	selection for stage 4	0~3	0	☆
PC. 28	Simplified PLC running time, segment 5	0.0s(h)~65 00. 0s (h)	0.0s (h)	☆
PC. 29	selection (segment 5)	0~3	0	☆
PC. 30	Simplified PLC	0.0s(h)~65 00. 0s (h)	0.0s (h)	☆

APV Pro Series Frequency Inverter Instruction Manual

	running time, segment 6			
PC. 31	selection for segment 6	0~3	0	☆
PC. 32	Simplified PLC running time segment 7	0.0s(h)~65 00. 0s (h)	0.0s (h)	☆
PC. 33	selection (segment 7)	0~3	0	☆
PC. 34	Simplified PLC running time segment 8	0.0s(h)~65 00. 0s (h)	0.0s (h)	☆
PC. 35	selection for segment 8	0~3	0	☆
PC. 36	Simplified PLC running time segment 9	0.0s(h)~65 00. 0s (h)	0.0s (h)	☆
PC. 37	Simple PLC 9th Segment Acceleration/Decel- eration Time Selection	0~3	0	☆
PC. 38	Simplified PLC running time of segment 10	0.0s(h)~65 00. 0s (h)	0.0s (h)	☆
PC. 39	selection for segment 10	0~3	0	☆
PC. 40	Simple PLC 11th segment running time	0.0s(h)~65 00. 0s (h)	0.0s (h)	☆
PC. 41	selection for segment 11	0~3	0	☆
PC. 42	Simple PLC 12th segment running time	0.0s(h)~65 00. 0s (h)	0.0s (h)	☆
PC. 43	Simple PLC 12th stage acceleration/decel- eration time selection	0~3	0	☆
PC. 44	Simplified PLC running time segment 13	0.0s(h)~65 00. 0s (h)	0.0s (h)	☆
PC. 45	selection (segment 13)	0~3	0	☆

APV Pro Series Frequency Inverter Instruction Manual

PC. 46	Simplified PLC running time segment 14	0.0s(h)~65 00. 0s (h)	0.0s (h)	☆
PC. 47	selection (segment 14)	0~3	0	☆
PC. 48	Simplified PLC, 15th segment running time	0.0s(h)~65 00. 0s (h)	0.0s (h)	☆
PC. 49	selection (segment 15)	0~3	0	☆
PC. 50	Simplified PLC running time unit	0: s (seconds) 1: h (hour)	0	☆
PC. 51	Multi-segment instruction 0 given mode	0: Function code PC.00 given 1: FIV 2: FIC 3: Retain 4: PULSE pulse 5: PID 6: The preset frequency (P0.08) is given. UP/DOWN can be modified	0	☆
P d group communication parameters				
PD. 00	baud rate	Units: MODBUS 0:300 BPS 1:600 BPS 2: 1200 BPS 3: 2400 BPS 4: 4800 BPS 5: 9600 BPS 6: 19200 BPS 7: 38400 BPS 8: 57600 BPS 9: 115200 BPS Tens: Reserved Hundreds: Reserved Thousands: CAN 0:20 KBPS 1:50 KBPS 2:100 KBPS 3:125 KBPS 4:250 KBPS 5:500 KBPS 6:1M BPS	0 005	☆
PD. 01	Data format	0: No checksum (8-N-2) 1: Even parity (8-E-1)	3	☆

APV Pro Series Frequency Inverter Instruction Manual

		2: Odd parity (8-O-1) 3:8-N-1		
PD. 02	Local address	1~247	1	☆
PD. 03	Response delay	0ms~20ms	2	☆
PD. 04	Communication timeout	0.0 (invalid), 0.1s~60.0s	0.0	☆
PD. 05	Data transmission format selection	Units: MODBUS 0: Non-standard MODBUS protocol 1: Standard MODBUS protocol Tens: Reserved	1	☆
PD. 06	Communication reading current resolution	0:0.01A 1:0.1A	1	☆
P P Group User function code				
PP. 00	User password	0~65535	0	☆
PP. 01	Parameter initialization	0: No operation 01: Restore factory settings, excluding motor parameters.	0	★
C0 group torque control parameters				
L 0.00	Speed/torque control mode selection	0: Speed Control 1: Torque Control	0	★
L 0.01	Torque setting source selection under torque control mode	0: Numeric setting (C0.03) 1: FIV 2: FIC 3: Retain 4: Retain 5: Communication given 6: MIN (FIV, FIC) 7: MAX(FIV,FIC) (The full scale of options 1-7 corresponds to the numerical setting C0.03)	0	★
L 0.03	Torque digital setting under torque control mode	-200.0%~200.0%	150.0%	☆
L 0.05	Torque control positive maximum frequency	0.00Hz to maximum frequency	50.00Hz	☆
L 0.06	Torque control reverse maximum frequency	0.00Hz to maximum frequency	50.00Hz	☆

APV Pro Series Frequency Inverter Instruction Manual

L 0.07	Torque control acceleration time	0.00s~65000s	0.00s	☆
L 0.08	Torque control deceleration time	0.00s~65000s	0.00s	☆
C 5 group of control optimization parameters				
L 5. 00	DPWM switching upper limit frequency	0.00Hz to maximum frequency	8.00Hz	☆
L 5. 01	PWM modulation method	0: Asynchronous modulation 1: Synchronous Modulation	0	☆
L 5. 02	Dead zone compensation mode selection	0: No compensation 1: Compensation Mode 1	1	☆
L 5. 03	Random PWM depth	0: Random PWM invalid 1-10: PWM carrier frequency random depth	0	☆
L 5. 04	Fast current limiting enable	0: Disable 1: Enable	1	☆
L 5.05	Voltage overmodulation coefficient	10 0~1 2 0	1 10	☆
L 5. 06	Undervoltage point setting	20.0 ~ 750.0	350.0	☆
L 5. 08	Dead Zone Time Adjustment	100%~200%	150%	☆
L 5.09	Overpressure point setting	650.0V ~ 2200.0V	Model confirmed	

Summary of monitoring parameters :

function	name	smallest unit
Group D0 Basic monitoring parameters		
D0.00	Operating frequency (Hz)	0.01Hz
D0. 01	Set frequency (Hz)	0.01Hz
D0.02	Bus voltage (V)	0.1V
D0. 03	Output voltage (V)	1V
D0. 04	Output current (A)	0.01A
D0.05	Output power (kW)	0.1kW
D0. 06	Output torque (%)	0.1%
D0. 07	DI Input Status	1
D0. 08	DO output status	1
D0. 09	FIV voltage (V)	0.01V
D0. 10	FIC voltage (V)	0.01V

APV Pro Series Frequency Inverter Instruction Manual

D0. 14	Load speed display	1
D0. 15	PID setting	1
D0. 16	PID feedback	1
D0. 17	PLC stage	1
D0. 20	Remaining running time	0.1 Min
D0. 21	FIV voltage before correction	0.001V
D0. 22	FIC voltage before correction	0.001V
D0. 25	Current power-on time	1 Min
D0. 26	Current running time	0.1 Min
D0. 28	Communication settings	0.01%
D0. 31	Auxiliary frequency Y display	0.01Hz
D0. 32	View arbitrary memory address	1
D0. 34	Motor temperature value	1 °C
D0. 35	Target torque (%)	0.1%
D0. 37	Power factor perspective	0.1°
D0. 39	VF separates the target voltage .	1V
D0. 40	VF separate output voltage	1V
D0. 45	Fault Information	0
D0.59	Set frequency (%)	0.01%
D0.60	Operating frequency (%)	0.01%
D0.61	Inverter status	1
D0.65	Multi-pump control steps	0: Shutdown
D0.66	Pressure stabilizing pump operating	
D0.6 7	Pump in state	0 : Shutdown 1 : Power Frequency 2 : Variable
D0.6 8	Pump in second state	0 : Shutdown 1 : Power Frequency 2 : Variable
D0.69	Pump three states	0 : Shutdown 1 : Power Frequency 2 : Variable
D0.70	Pump four states	0 : Shutdown 1 : Power Frequency 2 : Variable
D0.71	Multi-state observation	Bit0 : Terminal shuts off water pump number one Bit 1 : Terminal shuts off water pump number 2 Bit 2 : Terminal shut off water pump number 3 Bit 3 : Terminal shuts off water pump number four Bit 4 : Terminal shut off water pump number 5
D0.72	Current operating pump output	0.01Hz

APV Pro Series Frequency Inverter Instruction Manual

D0.73	Number of successful	1
D0.74	Number of successful	1
D0.75	Number of successful	1
D0.76	Number of successful	1
D0.77	Target frequency of host number	0.01Hz
D0.78	Target frequency of main unit two	0.01Hz
D0.79	Target frequency of host number	0.01Hz
D0.80	Target frequency of host number	0.01Hz
D0.81	Main unit output frequency	0.01Hz
D0.82	Second host output frequency	0.01Hz
D0.83	The output frequency of the third	0.01Hz
D0.84	The output frequency of the fourth	0.01Hz
D0.85	Output current of main unit No. 1	0.01A
D0.86	The No. 2 main unit outputs current.	0.01A
D0.87	The No. 3 host output current	0.01A
D0.88	The No. 4 main unit outputs current.	0.01A
D0.89	Mainframe failure	1
D0.90	Mainframe malfunction	1
D0.91	Mainframe No. 3 malfunction	1
D0.92	The No. 4 main unit malfunctioned.	1
D0.93	Output voltage of main unit No. 1	1V
D0.94	Output voltage of main unit number	1V
D0.95	Output voltage of host No. 3	1V
D0.96	No. 4 main unit output voltage	1V

Chapter 5 Troubleshooting and Repair

5-1 Fault alarms and countermeasures

The T200-BF frequency converter has multiple warning messages and protection functions. Once a fault occurs, the protection functions activate, the frequency converter stops outputting, the frequency converter fault relay contacts actuate, and a fault code is displayed on the frequency converter's display panel. When the user seeks service... Before proceeding, you can first perform a self-check as instructed in this section to analyze the cause of the fault and find a solution. If the cause falls under the category described in the dotted box, Please seek service by contacting the dealer of the inverter you purchased or by contacting our company directly.

In the fault information, OUOC is a hardware overcurrent or overvoltage signal. In most cases, hardware overvoltage faults will cause the OUOC alarm.

Fault 1 Name	Inverter unit protection
Operation panel display	OC
Troubleshooting	1. Short circuit in the inverter output circuit 2. The wiring between the motor and the frequency converter is too long. 3. Module overheating 4. Loose internal wiring of the frequency converter 5. Main control board malfunction 6. Driver board malfunction 7. Inverter module malfunction
Troubleshooting strategies	1. Troubleshoot external faults 2. Install a reactor or output filter 3. Check if the air duct is blocked, and if the fan is working properly, and troubleshoot any problems. 4. Connect all the connecting cables. 5. Seek technical support 6. Seek technical support 7. Seek technical support
Fault 2 Name	Accelerating overcurrent
Operation panel display	OC1
Troubleshooting	1. There is a grounding or short circuit in the inverter output circuit. 2. The control method is vector and no parameter identification is performed. 3. Acceleration time is too short 4. Manual torque boost or inappropriate V/F curve. 5. Low voltage

	6. Start the rotating motor. 7. Sudden load increase during acceleration 8. The selected frequency converter is too small.
Troubleshooting strategies	1. Troubleshoot external faults 2. Identify motor parameters 3. Increase acceleration time 4. Adjust the manual lifting torque or V/F curve. 5. Adjust the voltage to the normal range. 6. Select speed tracking start or wait for the motor to stop before starting. 7. Cancel sudden load increases 8. Select a frequency converter with a higher power rating.
Fault 3 Name	Deceleration overcurrent
Operation panel display	OC2
Troubleshooting	1. There is a grounding or short circuit in the inverter output circuit. 2. The control method is vector and no parameter identification is performed. 3. The deceleration time is too short. 4. Low voltage 5. Sudden load application during deceleration 6. No braking unit or braking resistor was installed.
Troubleshooting strategies	1. Troubleshoot external faults 2. Identify motor parameters 3. Increase deceleration time 4. Adjust the voltage to the normal range. 5. Cancel sudden load increases 6. Install a braking unit and resistor.
Fault 4 Name	Constant speed overcurrent
Operation panel display	OC3
Troubleshooting	1. There is a grounding or short circuit in the inverter output circuit. 2. The control method is vector and no parameter identification is performed. 3. Low voltage 4. Are there any sudden increases in load during operation? 5. The selected frequency converter is too small.
Troubleshooting strategies	1. Troubleshoot external faults 2. Identify motor parameters 3. Adjust the voltage to the normal range. 4. Cancel sudden load increases 5. Select a frequency converter with a higher power rating.

Fault 5 name	Accelerated overvoltage
Operation panel display	OU1
Troubleshooting	1. Input voltage is too high 2. During acceleration, an external force drives the motor. 3. Acceleration time is too short 4. No braking unit or braking resistor was installed.
Troubleshooting strategies	1. Adjust the voltage to the normal range. 2. Eliminate additional power or add a braking resistor. 3. Increase acceleration time 4. Install a braking unit and resistor.
Fault 6 Name	Deceleration overvoltage
Operation panel display	OU2
Troubleshooting	1. Input voltage is too high 2. During deceleration, an external force drives the motor. 3. Deceleration time is too short 4. No braking unit or braking resistor was installed.
Troubleshooting strategies	1. Adjust the voltage to the normal range. 2. Eliminate additional power or add a braking resistor. 3. Increase deceleration time 4. Install a braking unit and resistor.
Fault 7 name	Constant speed overvoltage
Operation panel display	OU3
Troubleshooting	1. Input voltage is too high 2. The motor is driven by an external force during operation.
Troubleshooting strategies	1. Adjust the voltage to the normal range. 2. Eliminate additional power or add a braking resistor.
Fault 8 Name	Control power failure
Operation panel display	POF
Troubleshooting	1. The input voltage is not within the range specified in the standard.
Troubleshooting strategies	1. Adjust the voltage to the specified range.
Fault 9 Name	Undervoltage fault
Operation panel display	LU
Troubleshooting	1. Instantaneous power outage 2. The voltage at the input terminal of the frequency converter is not within the range required by the specification.

	3. Abnormal bus voltage 4. The rectifier bridge and buffer resistor are not functioning properly. 5. Driver board malfunction 6. Control panel malfunction
Troubleshooting strategies	1. Reset fault 2. Adjust the voltage to the normal range. 3. Seek technical support 4. Seek technical support 5. Seek technical support 6. Seek technical support
Fault 10 Name	Inverter overload
Operation panel display	OL2
Troubleshooting	1. Is the load too large or is the motor stalled? 2. The selected frequency converter is too small.
Troubleshooting strategies	1. Reduce the load and check the condition of the motor and machinery. 2. Select a frequency converter with a higher power rating.
Fault 11 Name	Motor overload
Operation panel display	OL1
Troubleshooting	1. Is the setting of motor protection parameter P9.01 appropriate ? 2. Is the load too large or is the motor stalled? 3. The selected frequency converter is too small.
Troubleshooting strategies	1. Set this parameter correctly. 2. Reduce the load and check the condition of the motor and machinery. 3. Select a frequency converter with a higher power rating.
Fault 12 Name	Input phase loss
Operation panel display	LI
Troubleshooting	1. The three-phase input power supply is abnormal. 2. Driver board malfunction 3. Surge protection board malfunction 4. Main control board malfunction
Troubleshooting strategies	1. Inspect and eliminate problems in the external wiring. 2. Seek technical support 3. Seek technical support 4. Seek technical support
Fault 13 Name	Output phase loss
Operation panel display	LO

Troubleshooting	1. The wiring from the frequency converter to the motor is faulty. 2. The inverter's three-phase output is unbalanced when the motor is running. 3. Driver board malfunction 4. Module error
Troubleshooting strategies	1. Troubleshoot external faults 2. Check if the three-phase windings of the motor are normal and troubleshoot any faults. 3. Seek technical support 4. Seek technical support
Fault 14 Name	Module overheating
Operation panel display	OH
Troubleshooting	1. The ambient temperature is too high. 2. Duct blockage 3. Fan malfunction 4. Damaged module thermistor 5. Inverter module damaged
Troubleshooting strategies	1. Lower the ambient temperature 2. Clean the air ducts 3. Replace the fan 4. Replace the thermistor 5. Replace the inverter module
Fault 15 Name	External faults
Operation panel display	EF
Troubleshooting	1. Input external fault signals via the multi-function terminal.
Troubleshooting strategies	1. Reset Operation
Fault 16 Name	Communication failure
Operation panel display	CE
Troubleshooting	1. The host computer is not working properly. 2. The communication line is faulty. 3. Communication parameter P and D group settings are incorrect.
Troubleshooting strategies	1. Check the wiring of the host computer. 2. Check the communication connection cable 3. Correctly set communication parameters
Fault 17 Name	Contactor failure
Operation panel display	rAy

Troubleshooting	1. The driver board and power supply are not functioning properly. 2. The contactor is malfunctioning.
Troubleshooting strategies	1. Replace the driver board or power board. 2. Replace the contactor
Fault 18 Name	Current detection fault
Operation panel display	IE
Troubleshooting	1. Check for abnormalities in the Hall effect device. 2. Driver board malfunction
Troubleshooting strategies	1. Replace the Hall effect sensor 2. Replace the driver board
Fault 19 Name	Motor self-learning fault
Operation panel display	TE
Troubleshooting	1. Motor parameters are not set according to the nameplate. 2. Parameter identification process timed out.
Troubleshooting strategies	1. Set the motor parameters correctly according to the nameplate. 2. Check the leads from the frequency converter to the motor.
Fault 20 Name	reserve
Operation panel display	reserve
Troubleshooting	reserve
Troubleshooting strategies	reserve
Fault 21 Name	EEPROM read/write failure
Operation panel display	EEP
Troubleshooting	1. Damaged EEPROM chip
Troubleshooting strategies	1. Replace the main control board
Fault 22 Name	Inverter hardware failure
Operation panel display	OUOC
Troubleshooting	1. Overvoltage exists 2. Overcurrent exists.
Troubleshooting strategies	1. Handle as an overvoltage fault. 2. Handle as an overcurrent fault.
Fault 23 Name	short circuit to ground fault
Operation panel display	GND

Troubleshooting	1. Motor short circuit to ground
Troubleshooting strategies	1. Replace the cable or motor.
Fault 26 Name	Accumulated running time reaches fault
Operation panel display	END1
Troubleshooting	1. The cumulative running time has reached the set value.
Troubleshooting strategies	1. Use the parameter initialization function to clear the recorded information.
Fault 29 Name	The cumulative power-on time has reached the fault.
Operation panel display	END2
Troubleshooting	1. The cumulative power-on time has reached the set value.
Troubleshooting strategies	1. Use the parameter initialization function to clear the recorded information.
Fault 30 Name	Loading failure
Operation panel display	LOAD
Troubleshooting	1. The inverter's operating current is less than P9.64 .
Troubleshooting strategies	1. Confirm whether the load is disconnected or whether the P9.64 and P9.65 parameter settings match the actual operating conditions.
Fault 31 Name	Runtime PID feedback loss fault
Operation panel display	PIDE
Troubleshooting	1. The PID feedback is less than the PA setpoint .
Troubleshooting strategies	1. Check the PID feedback signal or set PA to a suitable value .
Fault 40 name	Wave-by-wave current limiting fault
Operation panel display	CBC
Troubleshooting	1. Is the load too large or is the motor stalled? 2. The selected frequency converter is too small.
Troubleshooting strategies	1. Reduce the load and check the condition of the motor and machinery. 2. Select a frequency converter with a higher power rating.
Fault 42 Name	Excessive speed deviation fault
Operation panel display	ESP
Troubleshooting	1. No parameter identification was performed. 2. Excessive speed deviation indicates that the detection parameters P9.69 and P9.60 are not set appropriately .
Troubleshooting	1. Identify motor parameters

strategies	2. Set the detection parameters reasonably according to the actual situation.
Fault 43 Name	Motor overspeed fault
Operation panel display	oSP
Troubleshooting	1. No parameter identification was performed.
Troubleshooting strategies	1. No parameter identification was performed.
Fault 51 Name	reserve
Operation panel display	reserve
Troubleshooting	reserve
Troubleshooting strategies	reserve

Chapter Six: Maintenance and Care

warn

Maintenance personnel must perform maintenance and upkeep according to the specified methods.

Maintenance personnel must be qualified professionals.

Before performing maintenance, the power supply to the frequency converter must be disconnected, and maintenance work can only be carried out after 10 minutes.

Do not touch the components on the PCB board directly, otherwise static electricity may damage the inverter.

- After the repair is completed, make sure all screws are tightened.

6-1 Routine Maintenance

To prevent inverter failures, ensure normal equipment operation, and extend the inverter's service life, routine maintenance is required. The routine maintenance procedures are as follows:

Inspection items	content
Temperature/Humidity	Confirm that the ambient temperature is between 0°C and 40°C, the humidity is between 20% and 90%, and there is no condensation.
oil mist and dust	Confirm that there is no oil mist, dust, or condensation inside the frequency converter.
frequency converter	Check the frequency converter for abnormal heating and vibration.
fan	Confirm that the fan is operating normally and there are no obstructions or other issues.
Input power	Confirm that the voltage and frequency of the input power supply are within the allowable range.
motor	Check the motor for abnormal vibration, overheating, abnormal noise, and phase loss.

6-2 Regular maintenance

To prevent inverter malfunctions and ensure its long-term high-performance and stable operation, users must conduct regular inspections (every six months). The inspection items are as follows:

Inspection items	Inspection content	Elimination methods
Screws for external terminals	Are the screws loose?	Tighten
PCB board	Dust, dirt	Use dry compressed air to thoroughly remove debris.

fan	Whether abnormal noise and vibration, and the cumulative time exceeds 20,000 hours.	1. Remove debris 2. Replace the fan
Electrolytic capacitors	Does it change color? Does it have an unusual odor?	Replace electrolytic capacitor
heat sink	Dust, dirt	Use dry compressed air to thoroughly remove debris.
Power components	Dust, dirt	Use dry compressed air to thoroughly remove debris.

6-3 Replacement of vulnerable parts for frequency converter

The fan and electrolytic capacitors in a frequency converter are easily damaged components. To ensure long-term, safe, and trouble-free operation of the frequency converter, these vulnerable parts must be replaced regularly.

The replacement schedule for vulnerable parts is as follows:

- ◆ Fan: Must be replaced after more than 20,000 hours of use.
- ◆ Electrolytic capacitors: need to be replaced after 30,000 to 40,000 hours of use.

Warranty of 6-4 frequency converter

Our company provides a 12-month warranty service for the T200-BF series frequency converters from the date of manufacture.

Appendix 1 One-click parameter setting for multiple pumps via communication

1) Multi-pump parameter settings:

For the main pump parameters (1 control 1), first set PP01 = 1 , then set the following parameters.

function code	name		PP01=30		
P002	Run selection	0~2	1		
P 003	Frequency source selection	0~9	8		
PA59	Multi-pump function effective	is 0~2	2		
P A62	Main pump selection	1: Main pump; 0: Slave pump	1		
P D 02	Local address	1~247	1		

One-to-many control: PA.58 is configured according to the number of control pumps.

1 for parameters 2-4 of the pump , then set the following parameters.

function code	name	content	PP01=31	PP01=32	PP01=33
P002	Run selection	0~2	2	2	2
P 003	Frequency source selection	0~9	9	9	9
PA59	Multi-pump function effective	is 0~2	0	0	0
P A62	Main pump selection	1: Main pump; 0: Slave pump	0	0	0
P D 02	Local address	1~247	2	3	4

2) Effective selection of each pump , the parameter set on the main pump frequency converter is PA.58 .

3) When controlling multiple pumps, the RS+ and RS- signals of each frequency converter are connected together.

Host:

- 1、PP.01=1 restores factory settings, then PP.01=30 sets host parameters.
- 2、PA.58 is configured according to the number of control pumps.

3、Start the machine according to the P002 startup method.

Slave:

Set the parameters directly with one click; once set, no modifications are needed. The only difference between each slave device is the PD.02 address.

Appendix II APV pro Modbus communication protocol

The T200-BF series frequency converters provide an RS485 communication interface and support the Modbus communication protocol. Users can... The computer or PLC can achieve centralized control, and the inverter's operation commands can be set, function code parameters can be modified or read, and the inverter's operating status and fault information can be read through this communication protocol.

I. Agreement Content

This serial communication protocol defines the information content and format used in serial communication. This includes: host polling (or wide-area polling)... (broadcast) format; host encoding method, including: function code requiring action, transmitted data, and error checking, etc. Slave response. It should also use the same structure, including: action confirmation, return data, and error verification. If the slave device receives information... If an error occurs, or if the action required by the host cannot be completed, it will organize a fault message as a response and send it back to the host.

II. Application Methods

The frequency converter is connected to a " single master, multiple slave " PC/PLC control network with an RS485 bus .

III. Bus Structure

(1) Interface method

RS485 hardware interface

(2) Transmission method Asynchronous serial, half-duplex transmission.

At any given time, only one of the master and slave devices can send data while the other can only receive data. Data is sent frame by frame in the serial asynchronous communication process.

(3) Topology A single-master, multiple-slave system. Slave addresses can be set from 1 to 247 , with 0 being the broadcast address. Slave addresses in the network must be unique.

IV. Agreement Description

The T200-BF series frequency converter uses an asynchronous serial master-slave Modbus communication protocol, where only one device exists in the network. The master (slave) can establish a protocol (called " query / command "). Other devices (slaves) can only respond to the master by providing data. The slave device receives a " query / command " from the host , or performs a corresponding action based on the host's " query / command " .

Here, the host refers to a personal computer (PC), industrial control equipment, or programmable logic controller (PLC), etc., while the slave device refers to the T200-BF frequency inverter. The host can communicate with a single slave device individually, or broadcast information to all slave devices. For individual host " queries / commands ", the slave device must return a message (called a response). For broadcast information sent by the host, the slave device does not need to send a response back to the host.

五、Communication Data Structure

Modbus protocol communication data format of the T200-BF series frequency converters is as follows: When using RTU mode, message sending must begin with a pause interval of at least 3.5 character times.

This is the easiest to implement at various character times under network baud rates. The first field transmitted is the device address.

The usable transmission characters are hexadecimal 0...9, A...F . Network devices continuously monitor the network bus, including during pause intervals. When the first field (address field) is received, each device decodes it to determine if it is destined for itself. After the last transmitted character, a pause of at least 3.5 characters marks the end of the message. A new message can be sent after this pause. start.

The entire message frame must be transmitted as a continuous stream. If there is a pause of more than 1.5 character times before the frame is completed, The receiving device will refresh the incomplete message and assume the next byte is the address field of a new message. Similarly, if a new message... If a message continues from the previous message within a time frame of less than 3.5 characters, the receiving device will interpret it as a continuation of the previous message. This will result in... An error has occurred because the value of the final CRC field cannot be correct.

RTU frame format:

Frame Header	3.5 character time
Slave Address	Mailing address: 1~247
Command code	03 : Read slave parameters; 06 : Write slave
Data content	Data contents: function code parameter address, number of function code parameters, function code parameter values, etc.
Data content	
...	
Data content	
CRC CHK high bit	Detection value: CRC value.
CRC CHK low bits	
END	3.5 character time

CMD (command instructions) and DATA (data description)

Command code: 03H , read N words (maximum 12 words can be read).

For example: frequency converter with slave address 01 . The device's starting address F1 0 5 reads two consecutive values.

Host command information

ADR	01H
CMD	03H
High bits of the starting	F 1 H
Starting address low bits	0 5 H
Number of registers (high-	00H
Register count (low byte)	02H
CRC CHK high bit	Its CRC CHK value needs to be calculated.
CRC CHK low bits	

Response information from the machine

PD. 05 is set to 0 :

ADR	01H
CMD	03H
Byte count (high bit)	00H
Byte count (low byte)	04H
Data F002H at a high level	00H
Data F002H at low levels	00H
Data F003H at a high level	00H
Data F003H at a high level	01H
CRC CHK high bit	Its CRC CHK value needs to be calculated.
CRC CHK low bits	

When PD. 05 is set to 1

ADR	01H
CMD	03H
Number of bytes	04H
Data F002H at a high level	00H
Data F002H at low levels	00H
Data F003H at a high level	00H
Data F003H low position	01H
CRC CHK high bit	Its CRC CHK value needs to be calculated.
CRC CHK low bits	

Command code: 06H Write a word (Word). For example: Write 3 000 (BB 8H) to the F00AH address of the slave inverter at address 0 5 H.

Host command information

ADR	0 5 H
CMD	06H
Data address high byte	F0H
Data address low bits	0AH
High level of data content	0B H

Data content at a low level	B 8H
CRC CHK high bit	CRC CHK value to be calculated
CRC CHK low bits	

Response information from the machine

ADR	0 5 H
CMD	06H
Data address high byte	F0H
Data address low bits	0AH
High level of data content	0B H
Data content at a low level	B 8H
CRC CHK high bit	CRC CHK value to be calculated
CRC CHK low bits	

Verification Method – CRC Verification: CRC (Cyclical Redundancy Check) uses the RTU frame format, message... This includes an error detection field based on the CRC method. The CRC field checks the entire message content. The CRC field is two bytes, containing a 16- bit binary value. It is calculated by the transmitting device and added to the message. The receiving device recalculates the CRC of the received message , and... If the two CRC values are not equal, it indicates that there is a transmission error.

The CRC algorithm first stores 0xFFFF , then calls a procedure to compare the value of 8 consecutive bytes from the message with the value in the current register. Line processing. Only the 8 bits of data in each character are valid for CRC ; the start bit, stop bit, and parity bit are invalid.

CRC generation, each 8- bit character is individually XORed with the register contents, and the result is shifted towards the least significant bit. The register is shifted, and the most significant bit is filled with 0. The LSB is extracted and checked; if the LSB is 1 , the register is checked separately and its value differs from the preset value. Alternatively, if the LSB is 0 , no action is taken. The entire process is repeated 8 times. After the last bit (the 8th bit) is completed, the next 8 -bit byte is XORed separately with the current value of the register. The final value in the register is the CRC value after all bytes in the message have been processed .

When adding a CRC to a message, the low byte is added first, followed by the high byte. The simple CRC function is as follows:

```

unsigned int crc_cal_value(unsigned char *data_value,unsigned char
data_length )
{
    int i;
    unsigned int crc_value=0xffff;
    while(data_length-- )
    {

```

```
crc_value^=*data_value++;  
for(i=0;i<8;i++)  
{  
  If(crc_value&0x0001 )  
    crc_value=(crc_value>>1 ) ^0xa001;  
  else  
    crc_value=crc_value>>1;  
}  
}  
Return(crc_value);  
}
```

Address definition of communication parameters

This section contains the communication information, used to control the operation of the frequency converter, its status, and related parameter settings. Read/write function code parameters (some function codes cannot be changed and are only for manufacturer or monitoring use): Function code parameter address identification rules:

The rule for representing parameter addresses using function code group numbers and labels is as follows:

High-order byte: F0 ~ FF (Group P), A0~ AF (Group C), 70~7F (Group D)

Low-order byte: 00~FF

For example: P3.12 , the address is represented as F30C ; Notice: P F group: Parameters cannot be read or modified; Group D: Read-only, parameters cannot be modified.

Some parameters cannot be changed when the frequency converter is running; others cannot be changed regardless of the frequency converter's state. When modifying function code parameters, pay attention to the parameter range, unit, and related instructions.

Furthermore, because EEPROM is frequently stored, its lifespan is reduced . Therefore, some function codes in communication... In this mode, there is no need to store the data; you only need to change the value in RAM .

change the high-order bit F of the function code address to 0 . If the parameter is from group C, to achieve this function, simply change the high-order bit A of the function code address to 4 . The corresponding function code address is represented as follows: High-order byte: 00~0F (Group P), 40~4F (Group C) Low-order byte: 00~FF

For example, function code P3.12 is not stored in EEPROM , and its address is represented as 030C ; Function code C0.05 is not stored in EEPROM ; its address is represented as 4005 . This address indicates that RAM can only be written to , not read from; it is an invalid address when reading from it.

Shutdown / Operation Parameters Section:

Parameter address	Parameter Description
-------------------	-----------------------

1000 (write only)	* Communication settings (-10000~10000)
1001 (Read-only)	Operating frequency
1002 (Read-only)	bus voltage
1003 (Read-only)	Output voltage
1004 (Read-only)	Output current
1005 (Read-only)	Output power
1006 (Read-only)	Output torque
1007 (Read-only)	running speed
1008 (Read-only)	Input terminal markings
1009 (Read-only)	Output terminal markings
100A (Read-only)	FIV voltage
100B (Read-only)	FIC voltage
100C (Read-only)	reserve
100D (Read-only)	Count value input
100E (Read-only)	Length value input
100F (Read-only)	Load speed (motor speed)
1010 (Read-only)	PID settings
1011 (Read-only)	PID feedback
1012 (Read-only)	PLC steps
1013 (Read-only)	PULSE input pulse frequency, in units of
1014 (Read-only)	reserve
1015 (Read-only)	Remaining running time
1016 (Read-only)	FIV voltage before correction
1017 (Read-only)	FIC voltage before correction
1018 (Read-only)	reserve
1019 (Read-only)	linear velocity
101A (Read-only)	Current power-on time
101B (Read-only)	Current running time
101C (Read-only)	PULSE input pulse frequency, in 1Hz
101D (Read-only)	Communication settings
101E (Read-only)	reserve
101F (Read-only)	Main frequency X display
1020 (Read-only)	Auxiliary frequency Y display

**** Notice:**

The communication settings are percentages of relative values; 10000 corresponds to 100.00% , and -10000 corresponds to -100.00% . For data in the dimension of frequency, this percentage is a percentage relative to the

maximum frequency (P0.10) ; for data in the dimension of torque, this percentage is P2.10 .

Control commands input to the frequency converter: (write only)

command address	Command Function
2000	0001 : Forward rotation
	0002 : Reverse operation
	0003 : Forward jogging
	0004 : Reverse inching
	0005 : Free Stop
	0006 : Deceleration and Stop
	0007 : Fault Reset

Read inverter status: (Read-only)

Status word address	Status word function
3000	0001 : Forward rotation
	0002 : Reverse operation
	0003 : Shutdown

Parameter lock password verification: (If the return value is 8888H , it means the password verification passed)

Password address	Enter the password content
1F00	*****

Output switch control: (write only)

command address	Command content
2001	BIT0 : Reserved BIT1 : Reserved BIT2 : TA-TC output control BIT3 : Reserved BIT4 : MOA-MOB-MOC Output Control

Analog output FOV control: (Write only)

command address	Command content
2002	0 to 7FFF represents 0 % to 100 %.

Analog output FOC control: (Write only)

command address	Command content
2003	0 to 7FFF represents 0 % to 100 %.

Pulse output control: (Write only)

command address	Command content
2004	0 to 7FFF represents 0 % to 100 %.

Inverter fault description:

Inverter fault address	Inverter fault information
8000	0000: No fault

	0001: Inverter Unit Protection 0002: Accelerating overcurrent 0003: Deceleration overcurrent 0004: Constant-speed overcurrent 0005: Accelerated overvoltage 0006: Deceleration overvoltage 0007: Constant-rate overvoltage 0008: Control power supply failure 0009: Undervoltage fault 000A: Inverter overload 000B: Motor overload 000C: Reserved 000D: Output phase loss 000E: Module overheating 000F: External Fault 0010: Communication error 0011: Contactor malfunction 0012: Current detection fault 0013: Motor self-learning fault 0014: Reserved 0015: Parameter read/write error 0016: Inverter hardware failure 0017: Motor to ground short circuit fault 0018: Reserved 0019: Reserved 001A: Runtime reached 001B: Reserved 001C: Reserved 001D: Power-on time reached 001E: Loadout 001F: PID feedback lost during runtime 0028: Fast rate limiting timeout fault 0029: Motor switching failure during operation 002A: Speed deviation is too large 002B: Motor Overspeed 002D: Motor overheating 005A: Encoder line count setting error 005B: Encoder not connected 005C: Initial position error 005E: Speed feedback error	
--	--	--

Communication Fault Address	Fault Function Description
8001	0000 : No fault 0001 : Incorrect password

	0002 : Command code error 0003 : CRC checksum error 0004 : Invalid address 0005 : Invalid parameter 0006 : Parameter change is invalid 0007 : System locked 0008 : EEPROM operation in progress
--	---

P D Group Communication Parameter Description

PD. 00	baud rate	Factory value	0 005
	Set range	Units: MODUBS baud rate 0 : 300 BPS 1 : 600 BPS 2 : 1200 BPS 3 : 2400 BPS 4 : 4800 BPS 5 : 9600 BPS 6 : 19200 BPS 7 : 38400 BPS 8 : 57600 BPS 9 : 115200 BPS Thousands: CAN 0:20 Kbps 1:50 Kbps 2:100 Kbps 3:125 Kbps 4:250 Kbps 5:500 Kbps 6:1M BPS	

This parameter sets the data transmission rate between the host computer and the frequency converter. Note that the baud rates set on the host computer and the frequency converter must be identical; otherwise, communication will fail. A higher baud rate results in faster communication.

PD. 01	Data format	Factory value	3
	Set range	0 : No validation: Data format <8,N,2> 1 : Even test: Data format <8,E,1> 2 : Odd parity: Data format <8,0,1> 3 : No validation: Data format <8 , N , 1>	

The data formats set by the host computer and the frequency converter

must be consistent; otherwise, communication will not be possible.

PD. 02	Local address	Factory	1
	Set range	1~247	

The local address is unique, which is the basis for realizing point-to-point communication between the host computer and the frequency converter.

PD. 03	Response delay	Factory	2ms
	Set range	0~20ms	

Response delay: refers to the time interval between the inverter finishing receiving data and sending data to the host computer. If the response delay is small... The response delay is based on the system processing time. If the response delay is longer than the system processing time, the system will wait for a delay after processing the data until the response delay time is up before sending the data to the host computer.

PD. 04	Communication timeout	Factory value	0.0 s
	Set range	0.0 s (invalid) 0.1~60.0s	

When the function code is set to 0.0 s , the communication timeout parameter is invalid.

When this function code is set to a valid value, if the interval between one communication and the next communication exceeds the communication timeout period, the system... The system will report a communication failure error (CE). Normally, this is set to disabled. However, in a continuous communication system... Setting this parameter allows you to monitor communication status.

PD. 05	Communication protocol selection	Factory value	1
	Set range	0 : Non-standard Modbus protocol 1 : Standard Modbus protocol	

PD. 05=1 : Select the standard Modbus protocol.

PD. 05=0 : When reading a command, the slave device returns one more byte than the standard Modbus protocol. See the " Communication Data Structure " section of this protocol for details .

PD. 0 6	Communication reading current resolution	Factory value	1
	Set range	0 : 0.01A 1 : 0.1A	

Used to determine the output unit of the current value when reading the output current for communication.